

## FlexTrack 45 PRO

EN

Operating Instructions  
Spare Parts List

Carriage





# Contents

<b>General information</b>	<b>7</b>
About this document.....	9
Function of this document .....	9
Explanation of safety notices .....	9
Qualified personnel .....	9
Copyright.....	9
<b>Safety</b>	<b>11</b>
Operational reliability and tips for the user .....	13
Proper use.....	13
Foreseeable misuse .....	13
Conversions or modifications .....	13
Duty to provide instruction.....	13
Operating Instructions .....	14
Personal protective equipment.....	14
National regulations .....	14
Spare parts, wearing parts and auxiliary materials .....	14
Transportation and storage .....	14
<b>Description of the carriage</b>	<b>15</b>
FlexTrack 45 Pro configurations.....	17
FlexTrack 45 Pro carriage configuration .....	17
FlexTrack 45 Pro rail configuration.....	18
FlexTrack 45 Pro ring rail configuration.....	18
Ring rail configuration according to work piece diameter.....	19
Carriage components .....	20
Structure of the carriage.....	20
Remote controls .....	20
Options and accessories .....	21
Radial oscillation unit .....	21
FMS slide .....	21
Trailer for wirefeeder .....	21
Mechanical seam tracking.....	22
Controls and connections .....	23
Connections .....	23
Control box .....	23
Control box control elements .....	24
Connections .....	24
Carriage.....	24
Carriage control elements .....	25
Welding position and weld seam tracking .....	26
Welding positions .....	26
Oscillating motion.....	27
<b>Commissioning</b>	<b>29</b>
Preparing the carriage.....	31
Mounting the carriage with a linear oscillation unit.....	31
Mounting the carriage with a linear oscillation unit and FMS slide.....	32
Replacing oscillation unit with adjustment unit.....	33
Assembly of FMS slide on the adjustment unit .....	34
Mounting the radial oscillation unit .....	35
Mounting the mechanical seam tracking.....	36

Preparing and installing guide rails .....	38
Fittings.....	38
Number of bridges required .....	38
Bridge types .....	39
Installing the bridges .....	40
Straight guide rails .....	41
Installing the actuating cams.....	41
Securing the rail structure .....	42
Rigid ring segments .....	42
Mounting on the component.....	43
Flexible ring segments .....	44
Ring segments with a defined radius .....	44
Vacuum rails - operating elements.....	46
Mounting vacuum rails .....	47
Securing vacuum rails.....	51
Removing vacuum rails .....	52
Commissioning the carriage .....	53
Placing the carriage on a straight guide rail .....	53
Placing the carriage on a circular guide rail .....	53
Disengaging the carriage .....	54
Setting the mechanical seam tracking (if used) .....	55
<b>Operation</b>	<b>56</b>
Connecting to the TPS power source.....	58
Configuration.....	58
CANopen.....	58
Image modes .....	58
Setting the NODE address ( <b>BASIC</b> and <b>PRO</b> remote Control) .....	58
Starting sequence .....	58
Connecting to the TPSi power source .....	59
Configuration.....	59
CANopen.....	59
Image modes .....	59
Setting the NODE address: Remote control <b>BASIC</b> .....	59
Setting the NODE address: Remote control <b>PRO</b> .....	60
Starting sequence .....	60
FRC-45 Basic remote control .....	61
Safety .....	61
FRC-45 Basic control elements .....	61
Define parameters for the carriage .....	63
Selecting additional functions.....	64
Saving a program.....	65
Loading the welding program.....	66
Changing the .....	67
units of measurement.....	67
FRC-45 Pro remote control .....	68
Safety .....	68
FRC-45 Pro control elements.....	68
Touch display .....	70
Standard software functions .....	71
Selecting a menu .....	71
Select a welding parameter.....	71
Editing parameters.....	71
Saving parameters .....	72
Service menu .....	73
Assigning function keys.....	73
Selecting power source .....	74

Loading welding program .....	75
Saving welding program.....	76
Selecting the language.....	76
Changing the units of measurement .....	78
<b>Menu description .....</b>	<b>79</b>
CARRIAGE menu.....	79
OSC menu.....	80
ACC menu.....	80
PS menu (Power Source) .....	81
ORBITAL menu .....	81
<b>ACC function .....</b>	<b>82</b>
General.....	82
Activating the ACC function:.....	82
FRC-45 Basic remote control.....	82
Activating the ACC function:.....	83
FRC-45 Pro remote control .....	83
ACC parameter .....	84
<b>ORBITAL function.....</b>	<b>85</b>
General.....	85
Activating ORBITAL function:.....	85
FRC-45 Basic remote control.....	85
Activating ORBITAL function:.....	86
FRC-45 Pro remote control .....	87
Orbital parameters.....	87
Segment parameters.....	89
<b>Starting welding: FRC-45 Basic .....</b>	<b>90</b>
Switching on system components .....	90
Working with or without an oscillation unit.....	90
Performing a test run.....	90
Starting the welding process .....	91
<b>Starting welding: FRC-45 Pro.....</b>	<b>92</b>
Switching on system components .....	92
Working with or without an oscillation unit.....	92
Performing a test run.....	92
Starting the welding process .....	93
<b>Maintenance and disposal</b>	<b>94</b>
<b>Troubleshooting.....</b>	<b>96</b>
General.....	96
Basic requirements for the system to work .....	96
Event codes .....	96
Remote control .....	96
FRC-45 Basic .....	96
FRC-45 Pro remote control event codes.....	96
Error code display .....	97
Error codes.....	97
<b>Maintenance.....</b>	<b>99</b>
Maintenance personnel .....	99
Maintenance record .....	99
Recommended lubricants .....	99
Maintenance intervals and procedures .....	100
Adjusting the gear rack play .....	103
<b>Technical data</b>	<b>104</b>
<b>Technical data .....</b>	<b>106</b>
FlexTrack 45 PRO Carriage .....	106
Control box .....	106

FRC-45 Basic and FRC-45 Pro.....	106
Linear oscillation unit.....	106
Radial oscillation unit .....	106
FMS 100/ML15/SE/ACC (optional) .....	107
FMS 50/ML15/SE/ACC (optional).....	107
Environmental conditions .....	107
Noise data .....	107
Dimensions.....	108
FMS slide dimensions .....	109
Weights of rails and bridges .....	109
Rating plates .....	110
Ring rail settings table .....	111
Flexible rail segments settings table .....	112
<b>Spare parts, Circuit Diagram</b>	<b>114</b>
Spare parts.....	116
Spare parts, wearing parts and auxiliary materials .....	116
Details required when placing orders .....	116
Carriage and accessories: .....	117
Connection cable: .....	117
Rails, bridges and ring rails for variable workpiece diameters: .....	118
Ring rail for defined workpiece diameters: .....	118
FlexTrack 45 Carriage Pro .....	119
FRC-45 Pro remote control .....	121
FRC-45 Basic remote control .....	122
FGU 8/SD80-28.....	123
FGU 9 / SD28.....	123
FOU 30 / ML 10 / linear .....	124
FOU 30 / ML6 / radial .....	125
FMS 100/ML15/SE/ACC .....	126
FMS 50/ML15/SE/ACC .....	127
Mechanical seam tracking.....	128
FTH 18/D16-25 .....	129
FTH 21 .....	129
Closed ring rail .....	130
Straight guide rails (rigid and flexible) .....	130
Vacuum bridge .....	131
Vacuum bridge with spacer block.....	132
Vacuum bridge with adjustment unit.....	133
Setting gauge .....	134
Wiring diagram .....	135
Declaration of conformity.....	141

# **General information**



# About this document

## Function of this document

These Operating Instructions explain how to commission and operate the device in conjunction with the installed system components. Look after the Operating Instructions carefully; they must always be to hand at the location where the device is being used. They can be used as a reference should any operational or functional problems occur in the future.

## Explanation of safety notices

### DANGER!

Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

### WARNING!

Indicates a hazard with a medium level of risk which, if not avoided, may result in death or serious injury.

### CAUTION!

Indicates a hazard with a low level of risk which, if not avoided, may result in minor or moderate injury.

### NOTICE!

Indicates a potentially hazardous situation which, if not avoided, may result in damage to the machine, equipment or workpiece.

**IMPORTANT!** Indicates tips for correct operation and other particularly useful information. This does not indicate a potentially hazardous situation.

Special care is required if you see any of the symbols shown.

## Qualified personnel

- These Operating Instructions are designed for trained personnel or persons with practical welding experience. Personnel must be trained through verifiable regular instruction.
- Maintenance and repair of the device may likewise only be carried out by trained technicians and in compliance with the specified maintenance activities and maintenance intervals.
- The manufacturer accepts no liability for damage caused by insufficient knowledge of how to use the device.

## Copyright

Copyright of these Operating Instructions remains with Fronius International GmbH. Text and illustrations were accurate at the time of printing. Fronius reserves the right to make changes. The contents of the Operating Instructions shall not provide the basis for any claims whatsoever on the part of the purchaser.



# **Safety**



# Operational reliability and tips for the user

## Proper use



The carriage must only be used for welding butt and fillet welds in a horizontal or vertical welding position.

Any other use shall be deemed improper and the manufacturer will assume no responsibility for any damages arising.

The carriage can be used in the following welding processes:

- MIG/MAG process
- CMT process

Proper use also includes:

- Carrying out all maintenance work at the specified maintenance intervals
- Keeping a service book with the necessary information (date, operator, activities carried out, etc.)
- Using the spare parts stipulated by Fronius
- Following all the instructions, particularly the safety instructions, in the Operating Instructions
- Using this document in conjunction with the Operating Instructions for the integrated system components (power source, etc.)

## Foreseeable misuse

Any use other than for the intended purpose shall be deemed improper use. This includes:

- Riding on the carriage, transporting loads
- Using the flexible (non-reinforced) rails on level surfaces
- Use above head height
- Hoisting processes (hoisting, manoeuvring of loads, animals or persons)
- Use as an aid to climbing
- Use as a tool shelf
- Use outside of the permitted technical operating limits (e.g. exceeding the max. permitted load)
- Use in hazardous areas

## Conversions or modifications

Any unauthorised conversions or modifications made to the carriage by the user shall invalidate all liability or warranty obligations on the part of the manufacturer!

The electromagnetic characteristics of the carriage can be adversely affected by additions or modifications of any kind. No modifications or upgrades should therefore be undertaken without first consulting the manufacturer and obtaining written approval.

## Duty to provide instruction

Before they start work, the system operator must instruct or train all persons working with the carriage in the following:

- Theoretical and practical aspects of operation
- Safety regulations

**IMPORTANT!** The duty to instruct also applies in particular to those who only occasionally work with the carriage. (e.g. during set-up, maintenance, etc.)

## **Operating Instructions**



The Operating Instructions help you to use the carriage safely and efficiently, and must therefore be to hand at all times.

- Keep the various sections of the Operating Instructions at the location where the carriage is being used at all times.
- Clearly mark the place where the instructions are kept.
- Ensure that all persons working with the carriage know where the Operating Instructions are located.
- The Operating Instructions will only be able to help you in the event of a problem if they are at hand!

**IMPORTANT!** The manufacturer shall not be liable for any damage that arises from failure to observe the Operating Instructions!

## **Personal protective equipment**

The operator alone is responsible for the immediate working environment.  
The following safety measures must be put in place and employed:



- Welding shield



- Safety helmet



- Welding gloves



- Welding apparel



- Safety footwear

**IMPORTANT!** Do not wear loose clothing and prevent long hair from being trapped when carrying out work on or using the carriage!

Risk of injury due to snagging or pulling in of clothes or hair.

## **National regulations**

In some countries, local statutory regulations may apply that are not included in these Operating Instructions. It is the duty of the operator to be aware of and comply with any local statutory regulations. This relates primarily to regulations concerning:

- Accident prevention
- Machine safety
- Protection of personnel (protective equipment)
- Environmental protection
- Electrical system

## **Spare parts, wearing parts and auxiliary materials**

Using spare parts and wearing parts from third-party manufacturers may pose risks. Use approved Fronius original spare parts only.

The manufacturer cannot accept any liability for damage resulting from the use of spare or wearing parts or auxiliary materials that are not approved by the manufacturer.

## **Transportation and storage**


The complete system, including tool kit, is supplied in a specially designed transport box. The rails must be stored separately.

# **Description of the carriage**




# FlexTrack 45 Pro configurations

## FlexTrack 45 Pro carriage configuration




- (1) FlexTrack 45 Pro carriage, including:
  - Control box with mains cable, (3 m)
  - Control box connection cable (10 m)
  - Power source connection cable, 9-pin plug (10 m)
  - Torch hosepack holder
  - Transport box
  - Tool kit
- (2) FRC-45 Pro remote control (without cable)
- (3) FRC-45 Basic remote control (without cable)
- (4) FRC-45 remote control cable (10 m)
- (5) FGU 8 adjustment unit
- (6) FOU 30 / ML10 linear oscillation unit
- (7) FGU 9 vertical adjustment unit
- (8) FTH 19 additional torch holder
- (9) FTH 18 torch holder
- (10) FTH 21 torch holder
- (11) FOU 30 / ML6 radial oscillation unit
- (12) Swivel adapter +/-45° for FOU 30 linear oscillation unit
- (13) FMS 100/ML15/SE/ACC
- (14) VR MW mounting lug
- (15) Trailer for FlexTrack wirefeeder
- (16) FST 95 seam tracking with FGU 9 angle bracket

## FlexTrack 45 Pro rail configuration





- (1) Straight rail
- (2) I-kit actuating cam rail (2 units are required)
- (3) Magnetic bridge with two manually operated permanent magnets
- (4) Vacuum bridge with two suction cups
- (5) Flexible rail
- (6) Magnetic bridge with two manually operated permanent magnets
- (7) Vacuum bridge with two suction cups
- (8) Eye bolt incl. locknut for securing load
- (9) Rail connector for the stable connection of straight rails

## FlexTrack 45 Pro ring rail configuration



- (1) Rigid ring rail, Ø 200-300 mm / 300-480 mm / 480-660 mm / 660-840 mm
- (2) Rigid ring rail, Ø 840-1020 mm / 1020-1200 mm / 1200-1380 mm / 1380-1380 mm
- (3) Rigid ring rail, Ø 1380-1560 mm
- (4) Adjustable magnetic bridge with two manually operated permanent magnets
- (5) Adjustable screw feet bridge, adjustment unit with metric scale and distance block
- (6) Flexible rail, 1130 mm / 1695 mm / 1884 mm
- (7) Eye bolt incl. locknut for securing load
- (8) Adjustable magnetic bridge
- (9) Adjustable vacuum bridge


## Ring rail configuration according to work piece diameter



- (1) Ring rail
- (2) Magnetic bridge
- (3) Spring holder

# Carriage components


Structure of the carriage



\* The radial oscillation unit or the FGU 8 adjustment unit can also be fitted as an option.

Remote controls

FRC-45 Basic



FRC-45 Pro




# Options and accessories

## Radial oscillation unit



The radial oscillation unit can be mounted on the left or the right of the carriage.  
Item no.: 8,045,590

## FMS slide




The FMS slide is available in two versions:  
- FMS 100/ML15/SE/ACC  
Item no. 8,045,599  
- FMS 50/ML15/SE/ACC  
Item no. 8,045,618

It can be used on the carriage without an oscillation unit, or in conjunction with the linear oscillation unit.  
It is used for automatic adjustment of the distance between the welding torch and the workpiece.


## Trailer for wirefeeder

Trailer for VR 4000, VR 5000 or WF 25i wirefeeder: Item no.: 48,0005,2599  
Mounting lug: Item no.: 42,0001,3752

**IMPORTANT!** Only suitable for use with rigid rails in the PA position - magnetic bridge/vacuum bridge in horizontal position!



## Mechanical seam tracking




The mechanical seam tracking can be used with a linear oscillation unit as well as with the FGU 8 adjustment unit.

Use with linear oscillation unit: mount above additional FGU 9 adjustment unit; linear oscillation unit serves as an adjustment slide.


Use with adjustment unit: mount directly to the FGU 8 adjustment unit.

# Controls and connections

## Connections Control box



(1) Control box mains cable



- (2) Connection for control line between carriage and control box
- (3) Connection for connection cable between control box and power source 2 with CAN communication
- (4) Connection for control line between control box and remote control
- (5) Connection for connection cable between control box and power source 1 with CAN communication
- (6) Connection for the connection cable between the control box and power source without CAN communication

**Control box  
control elements**



**(1) ON/OFF switch**

Switches the control box on and off

**Connections  
Carriage**



**(1) Connection for linear oscillation unit**

**(2) Connection for FMS 50 or FMS 100, or radial oscillation unit**

**(3) Connection for control line between carriage and control box**

## Carriage control elements



### (1) Coupling on/off

Locks/unlocks the carriage drive unit on the rail. Allows rapid positioning of the carriage.

### (2) Guide rollers locking lever

Fixes and releases the internal guide rollers.

### (3) Limit switch (both sides, in and against direction of travel)

For automatic stopping or changing of direction.

**IMPORTANT!** A detailed description of the FRC-45 Basic and FRC-45 Pro remote controls can be found in the OPERATION section.


# Welding position and weld seam tracking

## Welding positions

### NOTICE!

In vertical applications, the rail structure must be secured by a load arrestor with a locking function to prevent it from falling. The load arrestor must be designed for the total weight of the carriage and rail structure. The manufacturer accepts no liability for any damage to persons or property resulting from vertical use of the carriage without a load arrestor.


#### Horizontal position on rigid rail:



##### Possible welding positions:

- PA (flat position)
- PB (horizontal-vertical position)
- PC (horizontal position)


#### Vertical position on rigid rail:



##### Possible welding positions:

- PG (descending position)
- PF (ascending position)


#### Position on flexible rail:



##### Possible welding positions:

- PA (flat position)
- PB (horizontal-vertical position)
- PC (horizontal position)
- PG (descending position)
- PF (ascending position)

#### Position on ring rail (rigid or flexible)




##### Possible welding positions:

- PA (flat position)
- PB (horizontal-vertical position)
- PC (horizontal position)
- PG (descending position)
- PF (ascending position)

## Welding positions (continued)


### Overhead position




The carriage is NOT suitable for the PE and PD positions (overhead / horizontal-overhead). Use in this manner shall be deemed improper!

## Oscillating motion

### Linear oscillation unit



### Radial oscillation unit





# **Commissioning**




# Preparing the carriage


## Mounting the carriage with a linear oscillation unit

### Mounting the carriage with a linear oscillation unit:

1. Connect the oscillation unit to the carriage using the six screws supplied.
2. Connect the connecting lead for the oscillation unit to the carriage and lock it in place.
3. Push the torch holder onto the oscillation unit.
4. Tighten the screws.
5. Fit the horizontal support onto the torch holder and tighten the screws.
6. Feed in the hosepack holder and fix it in place with the clamp lever.




7. Establish the connections: see diagram below




**Mounting the carriage with a linear oscillation unit and FMS slide**

**Mounting the carriage with a linear oscillation unit and FMS slide:**

1. Push the torch holder onto the oscillation unit.
2. Tighten the screws.




3. Secure the FMS slide on the torch holder and close the clamping lever.
4. Connect the connection cable for the FMS slide to the carriage.



**Mounting the carriage with a linear oscillation unit and FMS slide**  
 (continued)


5. Establish the connections: see diagram below.



**Replacing oscillation unit with adjustment unit**

**Replacing the linear oscillation unit with an adjustment unit:**


1. Undo the six M6 screws and remove the oscillation unit.
  2. Disconnect the connecting lead for the oscillation unit from the carriage.  
 Place the protective cap onto the socket for the oscillation unit.
  3. Fasten the adjustment unit to the welding carriage using four M6 screws.
- IMPORTANT!** Reverse this sequence when replacing the adjustment unit with the oscillation unit.




## Assembly of FMS slide on the adjustment unit

### Mounting the FMS slide on the adjustment unit:


1. Position the FMS slide on the adjustment unit and close the clamping lever.
2. Attach the torch holder to the FMS slide and close the clamping lever.
3. Plug the FMS connection cable into the oscillation unit socket.



4. Establish the connections: see diagram below.




## Mounting the radial oscillation unit



### Mounting the radial oscillation unit onto the adjustment unit:


1. Mount the adjustment unit as described under "Replacing oscillation unit with adjustment unit"
2. Push the vertical bolt into the horizontal holder and secure using the clamping lever.
3. Connect the connecting lead for the oscillation unit to the carriage and lock it in place.
4. Establish the connections: see diagram below.



**Mounting the mechanical seam tracking**


**Mounting the mechanical seam tracking onto the linear oscillation unit:**

1. Mount the FGU 9 adjustment unit onto the linear oscillation unit.
2. Fit the mechanical seam tracking adjustable bracket to the FGU 9 adjustment unit using the four screws.




**Mounting the mechanical seam tracking onto the adjustment unit:**

1. Remove the plate using the clamping lever.




**Mounting the  
mechanical seam  
tracking**  
(continued)

2. Fit the mechanical seam tracking adjustable bracket to the FGU 8 adjustment unit using the four screws.




# Preparing and installing guide rails

## Fittings



## Connection pieces:

Two connection pieces to extend the rails are included with every rail.




## Actuating cam installation kit:

Two actuating cams to trigger the limit switch at the beginning and end of the guide rail.

### NOTICE!

If actuating cams are not used, there is a risk that the carriage might travel beyond the end of the rail and fall off.



## Rail connector:

For the stable connection of straight rails.

## Number of bridges required

**IMPORTANT!** The specified number of bridges is applicable when using magnetic bridges as well as when using vacuum bridges.

### Straight, rigid rails:

- For a rail length of 1884 mm: use 3 bridges.

### Straight, flexible rails:


- For a rail length of 1884 mm: use 5 bridges.
- For a rail length of 1695.6 mm: use 4 bridges.
- For a rail length of 1130.4 mm: use 3 bridges.

### Closed ring rails and ring rails made from rail segments:


- The number of bridges required depends on the ring diameter and should be taken from the settings table.

## Bridge types

### For ring segments with a fixed radius

MAGNETIC BRIDGE	SPRING SUPPORT
 <p>Magnetic bridges for ring segments with a fixed radius for mounting on ferritic components. Height adjustment: 10 mm (0.39 inch).</p>	 <p>Spring pressure spacer for ring segments with a fixed radius. Can also be used with non-ferritic components.</p>

### For flexible and rigid rails and closed ring rails

MAGNETIC BRIDGE	VACUUM BRIDGE	SCREW FEET BRIDGE
 <p>For ferritic components. Heat-resistant up to 180°C. The magnetic force is controlled by a lever.  Maximum holding force of a magnetic bridge: 750 N</p>	 <p>Components with smooth surfaces, such as aluminum or stainless steel. Operating temperature: 0°C to 120°C (optional from -30°C to 250°C).</p>	 <p>For rigid rings up to 840 mm (33 inch) in diameter.</p>

### NOTICE!

Take care when welding preheated components. As additional heat is generated during the welding process, take extra care to avoid exceeding the temperature required to maintain the holding force of the magnets.


**IMPORTANT!** All bridges include a metric adjustment unit and a spacer.

## Installing the bridges

### Bridge without spacer and adjustment unit:


Fit the rail to the bridge using the two M6x65 screws and counter them using the two M6 nuts.

**IMPORTANT!** The mounting positions for the bridges are marked: in the middle of the rail there is a recess for the adjustment unit adjusting screw.



### Bridge with adjustment unit:


Bridges with an adjustment unit are installed using the M6x14 screws supplied.



The scale on the side of the adjustment unit is fixed in place using the M4x10 screw supplied.

## Straight guide rails

Both rigid and flexible straight guide rails can easily be extended using the joining elements supplied.



1. Set the levers on the magnetic bridges (1) to OFF.
2. Place the rail section on the workpiece and set the levers on the magnetic bridges to ON.
3. Fit the joining element (2) at the end of the straight rail.
4. Loosen both M6 screws (3).
5. On the next section of rail, set the levers on the magnetic bridges to OFF.
6. Push the next section of rail with the groove (4) between the joining element (2) and the screw (3).
7. Tighten both M6 screws (3).
8. Align the rail if necessary, then set the levers on the magnetic bridges to ON.
9. Install further rail sections as described above until the rail has reached the required length.
10. Install an actuating cam for the limit switch at the beginning and end of the rail.

## Installing the actuating cams

**IMPORTANT!** If actuating cams are not used, there is a risk that the carriage might travel beyond the end of the rail and fall off!

In rail structures with open ends (not rings), actuating cams (limit switch installation kit) must be installed at both ends.

## Securing the rail structure

**IMPORTANT!** In vertical applications, the rail structure must be secured by a load arrestor with a locking function to prevent it from falling.

The load arrestor must be designed for the total weight of the carriage and rail structure. The manufacturer accepts no liability for any damage to persons or property resulting from vertical use of the carriage without a load arrestor.

### NOTICE!

Ensure that the cable on the load arrestor is kept permanently taut. Check the load arrestor for damage before use.



## Rigid ring segments

Rigid ring segments can be joined to create ring rails with a maximum diameter of 1560 mm (4 segments). The individual segments are joined to form a ring rail using locking catches and M6x20 socket screws.

The number of segments used and the bridges required for different pipe diameters are set out in the table below:


Diameter	Segments	Bridges
200 - 300 mm (7.9 - 11.8 in.)	2	3
300 - 480 mm (11.8 - 18.9 in.)	2	4
480 - 660 mm (18.9 - 26 in.)	2	6
660 - 840 mm (26 - 33.1 in.)	2	8
840 - 1020 mm (33.1 - 40.2 in.)	3	9
1020 - 1200 mm (40.2 - 47.2 in.)	3	12
1200 - 1380 mm (47.2 - 54.3 in.)	3	15
1380 - 1560 mm (54.3 - 61.4 in.)	4	16

1. Join two ring segments. Tighten the top four M6x20 screws (a) slightly.
2. Lock the locking hook (b) on the lower guide section. Tighten the two lower M6x16 screws (c) slightly.




**Rigid ring segments**  
(continued)

3. Engage the upper locking hook (d).
4. If necessary, align the two segments with one another.  
Tighten all the M6 screws (4 at the top, 2 at the bottom).



**Mounting on the component**

1. It is recommended that two people should work together when installing a ring rail made from rail segments.
2. When using magnetic bridges: Set the lever on the bridges to OFF.
3. Use the adjusting screw (d) to set the clearance on the adjustment units of the bridges. For the recommended setting M, please refer to the settings table. When installing the rings, set them initially to 3 mm more than is shown in the table on the adjustment unit.



4. Install the ring rail on the component.
5. Using the adjusting screws (d) on the bridges, fit the ring rail evenly around the component.
6. When using magnetic bridges: set all the levers on the magnetic bridges to ON.

## Flexible ring segments

Flexible ring segments can be joined to create ring rails with a diameter of 1560 mm to 6060 mm (up to 11 segments).


The individual segments are joined to form a ring rail using M6x20 socket screws. Flexible segments are available in the following lengths:

SEGMENT TYPE	LENGTH
Type I	1130.4 mm
Type II	1695.6 mm
Type III	1884 mm

The number of segments and bridges used depends on the pipe diameter and can be selected using the table below:

Diameter	Segments	Bridges
1560 - 1740 mm (61.4 - 68.5 in.)	3x type I 1x type II	18
1740 - 1920 mm (68.5 - 75.6 in.)	3x type III 1x type I	18
1920 - 2100 mm (75.6 - 82.7 in.)	3x type III 1x type II	20
2100 - 2280 mm (82.7 - 89.8 in.)	3x type III 2x type I	21
2280 - 2460 mm (89.8 - 95.9 in.)	5x type II	25
2460 - 2640 mm (95.9 - 103.9 in.)	3x type III 2x type II	25
2640 - 2820 mm (103.9 - 111 in.)	5x type II 1x type I	25
2820 - 3000 mm (111 - 118.1 in.)	6x type II	28
3000 - 3180 mm (118.1 - 125.2 in.)	3x type III 3x type II	30
3180 - 3360 mm (125.2 - 132.3 in.)	6 x type III	30
3360 - 6060 mm (132.3 - 238.6 in.)	On request	

## Ring segments with a defined radius



These ring rails are designed for fixed workpiece diameters. Suitable for orbital welding applications with an external pipe diameter ranging from 254 - 1778 mm (10 - 70 inch).

Especially easy and fast to attach to the component due to pre-contoured rail segments with pre-fitted bridge elements and quick-clamping system.


**Ring segments  
with a defined  
radius**  
(continued)

The number of bridges required can be found in the following table:

Diameter	Magnetic bridges	Spring pressure spacer
254,0 mm (10 in)	4	8
304,8 mm (12 in)	6	12
355,6 mm (14 in)	6	12
406,4 mm (16 in)	6	12
457,2 mm (18 in)	6	12
508,0 mm (20 in)	8	16
558,8 mm (22 in)	8	16
609,6 mm (24 in)	8	16
660,4 mm (26 in)	8	16
711,2 mm (28 in)	10	20
762,0 mm (30 in)	10	20
812,8 mm (32 in)	10	20
863,6 mm (34 in)	10	20
914,4 mm (36 in)	12	24
965,2 mm (38 in)	12	24
1016,0 mm (40 in)	12	24
1066,8 mm (42 in)	15	30
1117,6 mm (44 in)	15	30
1168,4 mm (46 in)	15	30
1219,2 mm (48 in)	15	30
1270,0 mm (50 in)	15	30
1320,8 mm (52 in)	15	30
1371,6 mm (54 in)	16	32
1422,4 mm (56 in)	16	32
1473,2 mm (58 in)	20	40
1524,0 mm (60 in)	20	40
1574,8 mm (62 in)	20	40
1625,6 mm (64 in)	20	40
1676,4 mm (66 in)	20	40
1727,2 mm (68 in)	20	40
1778,0 mm (70 in)	20	40


**Vacuum rails**  
- operating  
elements

- ① Vacuum line shut-off valve
- ② Vacuum suction cup shut-off valves



## Mounting vacuum rails

**IMPORTANT!** At least two persons are required to install the rail system.




1. Make sure that the shut-off valve for the vacuum line is closed.



Shut-off valve closed



Shut-off valve open



2. Close the shut-off valves of the vacuum cups.





Shut-off valve closed



Shut-off valve open


**Mounting  
vacuum rails**  
(continued)




3. Connect the vacuum pump (a) to the first rail segment and switch on.
4. Place the rail segment on the part.
5. Open the shut-off valves of the suction feet one after the other in the numbered sequence (1 to 4).
6. Hook the load arrestor into the eye bolts on the first and last vacuum bridge of the rail segment.

7. Before mounting the next rail segment, make sure that
  - The shut-off valve of the supply line is closed
  - All shut-off valves of the vacuum feet are closed

**Mounting  
vacuum rails**  
(continued)




8. Connect the rail segments with the connecting elements.
9. Connect the vacuum line.



10. Hook the load arrestor into the eye bolts on the first and last vacuum bridge of the rail segment just mounted.
11. Open the shut-off valve of the vacuum line on rail segment 1.

**Mounting  
vacuum rails**  
(continued)



12. Open the shut-off valves of the suction feet on rail segment 2 in the numbered sequence (1 to 4).
13. To install each additional rail segment, repeat points 7 to 12.

## Securing vacuum rails


**IMPORTANT!** A failure of the vacuum pump or improper handling of the vacuum equipment can cause the trolley and rail construction to fall.\* For this reason, the rail construction must be secured against falling during vertical use by means of a load arrestor with blocking function. The load arrestor must be designed for the total weight of the trolley and rail construction. The manufacturer does not accept any liability for personal injury or damage to property resulting from vertical use of the trolley without load arrestor!

### NOTICE!

Ensure that the rope of the load arrestor is permanently kept under tension! Check load arrestor for damage before use.


See also Operating Instructions "Vacuum pump FlexTrack 45".

Eye bolt 48,0005,1830  
for mounting the  
load arrestor




## Removing vacuum rails

**IMPORTANT!** At least two persons are required to remove the rail system.



1. Loosen the connection screws between the penultimate and last rail segment.



2. Hold the last rail segment in place. Close the shut-off valve of the vacuum line on the penultimate rail segment.
3. Disconnect the vacuum supply line.

4. Carefully remove the rail segment and unhook the load arrestor.
5. So that the rail segment is immediately ready for the next application, close all shut-off valves again.
6. To remove the next rail segment, repeat points 1 to 5.


# Commissioning the carriage

## Placing the carriage on a straight guide rail

1. Remove the remote control. The carriage must be installed on the guide rail without the remote control.
2. Set the mains switch on the control box to ON.
3. Coupling and levers for the rollers in the "OFF" position.
4. Lift the carriage using the handles and place it on the rails.
5. Set the lever for the adjustable pressure rollers to the "ON" position.
6. Manually pull the carriage along the full length of the rail once to check whether the welding torch remains at a constant distance from the workpiece. If the distance is not constant, set the correct distance "M" on the relevant bridges.
7. Push the carriage along the rail. At the same time, set the coupling to the "ON" position to engage the gearbox unit with the openings on the guide rail.
8. Check the following switches on the remote control:
  - Welding mode switch in position "0"
  - Change direction / stop in the central position switch (only with BASIC remote controls).

## Placing the carriage on a circular guide rail

1. Remove the remote control. The carriage must be installed on the guide rail without the remote control.
2. Set the mains switch on the control box to ON.
3. Coupling and levers for the rollers in the "OFF" position.
4. Loosen the three M6x20 holding the pressure rollers in place, on both sides.
5. Place the carriage horizontally on the rail above the centre of the workpiece and hold it by the handle.



6. Set the lever for the adjustable pressure rollers to the "ON" position.

**Placing the carriage on a circular guide rail**  
(continued)

7. Tighten the three M6 mounting screws on both sides.
8. Manually pull the carriage along the full length of the rail once to check whether the welding torch remains at a constant distance from the workpiece. If the distance is not constant, set the correct distance "M" on the relevant bridges.
9. Push the carriage along the rail. At the same time, set the coupling to the "ON" position to engage the gearbox unit with the openings on the guide rail.
- 10 Check the following switches on the remote control:
  - Welding mode switch in position "0"
  - Change direction / stop switch in the central position (only applicable for the BASIC remote control).


**Disengaging the carriage**

To attain optimum wirefeed, observe the following when laying the hosepack:

- Do not allow the hosepack to become kinked
- Always lay the hosepack as straight as possible

**NOTICE!**

Observe the maximum tensile load on the hosepack holder (see the "Technical data" section). This value must not be exceeded.



1. Undo the knurled screw (a) on the clamp.

2. Insert the hosepack as illustrated

**IMPORTANT!** Do not kink the hosepack. This can cause wirefeed problems.


3. Tighten the knurled screw (a)



## **Setting the mechanical seam tracking (if used)**

The mounting plate (a) for the guide rollers has five holes in which the rollers can be placed and secured.

The rollers can be secured in these holes using the fixing screws (b).



1. Undo the fixing screws (b) for the chosen holes.
2. Position the guide rollers at the desired height.(c).
3. Tighten the fixing screws (b) again.

# **Operation**



# Connecting to the TPS power source


<b>Configuration</b>	1pc 38,0100,0457 Connection cable between CanOpen and control box, 5 m
	1pc 4,100,251 RI MOD/i CC CANopen

CANopen  
Image modes

DIP switch								
8	7	6	5	4	3	2	1	Configuration
OFF	OFF	-	-	-	-	-	-	Standard image 320 bit
OFF	ON	-	-	-	-	-	-	Economy image 128 bit
ON	OFF	-	-	-	-	-	-	Retrofit: Scope depends on the bus module
ON	ON	-	-	-	-	-	-	Not used

Setting the NODE address (**BASIC** and **PRO** remote Control)

DIP switch								NODE address = 6
1	2	3	4	5	6	7	8	Node address
OFF	ON	ON	OFF	OFF	OFF	ON	ON	6



Starting sequence

1. Switch on the TPS power source.
2. Wait until the power source is fully powered up.
3. Now switch in the FlexTrack control box.

# Connecting to the TPSi power source

## Configuration

1pc	38,0100,0463	Data cable between control box and power source, 2 m
1pc	4,044,014,IK	RI FB Inside/i - Factory installation
1pc	4,044,014,CK	RI FB Inside/i - Customer installation
1pc	41,0018,0081	RI MOD/i CC CANopen


## CANopen Image modes

DIP switch								Configuration
8	7	6	5	4	3	2	1	
OFF	OFF	-	-	-	-	-	-	Standard image 320 bit
OFF	ON	-	-	-	-	-	-	Economy image 128 bit
ON	OFF	-	-	-	-	-	-	Retrofit: Scope depends on the bus module
ON	∞	-	-	-	-	-	-	Not used

## Setting the NODE address: Remote control **BASIC**

DIP switch								Node address
1	2	3	4	5	6	7	8	
OFF	∞	∞	OFF	OFF	OFF	OFF	∞	6


NODE address = 6  
(including Retrofit mode)



**Setting the NODE address: Remote control PRO**

DIP switch									Node address
1	2	3	4	5	6	7	8		
OFF	ON	ON	OFF	OFF	OFF	ON	OFF		6

NODE address = 6  
(including Retrofit mode)



**Starting sequence**

1. Switch on the TPS power source.
2. Wait until the power source is fully powered up.
3. Now switch in the FlexTrack control box.

# FRC-45 Basic remote control

## Safety



### WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described here until you have fully read and understood the following documents:

- These Operating Instructions
- All the Operating Instructions for the system components, especially the safety rules.


## FRC-45 Basic control elements



**FRC-45 Basic control elements**  
(continued)

- (1) **Numerical display, 4 digits (metric / imperial)**  
Displays welding parameters and error codes.
- (2) **Limit switch function, change direction / stop**  
Depending on the switch position, the welding carriage changes direction or stops as soon as the limit switch is activated.
- (3a) **Dwell time, left / return travel path**
  - White symbol: Oscillation dwell time, left**  
Regulates the oscillation dwell time on the left.
  - Yellow symbol: Return travel path**  
Return time at the end of the welding path in seconds [s].
- (3b) **Dwell time, middle / segment welding**
  - White symbol: Oscillation dwell time, middle**  
Regulates the oscillation dwell time in the middle of the oscillation motion.
  - Yellow symbol: Segment path with welding**  
Sets the length of the individual welding segments in [cm].
- (3c) **Dwell time, right / segment path without welding**
  - White symbol: Oscillation dwell time, right**  
Regulates the oscillation dwell time on the right.
  - Yellow symbol: Segment path without welding**  
Sets the distances between the individual segments in [cm].
- (4) **Oscillation speed**  
Regulates the oscillation speed:  
  - in [cm/min] for the linear oscillation unit
  - in [%] for the radial oscillation unit
- (5) **Offset**  
Regulates the offset during oscillation.
- (6) **Traversing direction**  
Selects the traversing direction.
- (7) **Travel speed**  
Regulates the travel speed of the welding carriage.
- (8) **Welding mode**  
3 welding modes can be selected:  
  - Test
  - Without arc (O)
  - With arc (I)

**(9) Selector switch**



**(a) White symbols: Oscillation mode**

Four oscillation modes can be selected:

- No oscillation
- Trapezoidal oscillation
- Triangular oscillation
- Rectangular oscillation

- (b) Yellow marking: Preset segment welding**  
Preset to select the additional segment welding functions (yellow symbols).  
**IMPORTANT!** The welding process cannot start until the oscillation mode adjusting knob (9) is set to one of the white function parameters.
- (c) Green marking: Preset path measurement**  
Preset to select the additional path measurement function (green symbol) on the oscillation path button (10).  
**IMPORTANT!** The welding process cannot start until the oscillation mode adjusting knob (9) is set to one of the white function parameters.
- (d) ACC option**  
Regulates the distance between the welding torch and the workpiece.  
**IMPORTANT!** For a detailed description of the ACC function, see the chapter entitled "ACC FUNCTION".
- (e) ORBITAL option**  
**IMPORTANT!** For a detailed description of the orbital function, see the chapter entitled "ORBITAL FUNCTION".
- (10) Oscillation path / total welding path**
- White symbol: Oscillation path**  
Regulates the oscillation path:  
- in [cm/min] for the linear oscillation unit  
- in [%] for the radial oscillation unit
- Green symbol: Total welding path**  
Total welding path in [cm].
- (11) End-crater filling time / start-up delay**
- White symbol: End-crater filling time**  
Period of time, in which the carriage remains at the weld seam end, to fill the end crater.
- IMPORTANT:** Parameters must be entered via the power source and must be either equal to or greater than the original power source value (End current time).
- Yellow symbol: Start-up delay / Flying-start**  
If value is positive – start-up delay [s]: Start welding -> Dwell time elapses -> Carriage starts to move.  
If value is negative – flying-start [s]: Carriage starts to move. The arc does not ignite until the "flying start" time has expired.

**Define  
parameters for  
the carriage**

**NOTICE!**

The oscillation unit must be connected to the welding carriage when saving programs with oscillation parameters.

The remote control can be used to configure 9 welding programs with the following parameters:

**With oscillation:**

- Travel speed
- Oscillation path
- Oscillation speed
- Dwell time, left
- Dwell time, middle
- Dwell time, right
- End-crater filling time

**Without oscillation:**

- Travel speed
- End-crater filling time

**Additional functions:**

- Path measurement (green markings)
- Segment welding (yellow markings)


**Define  
parameters for  
the carriage  
(continued)**

To set a parameter, turn the corresponding adjusting knob:  
to the right: to increase the value  
to the left: to reduce the value  
When a setting has been adjusted, the value of the parameter is shown on the display.  
Press the adjusting knob to save the value for the setting.


**Selecting  
additional  
functions**

**IMPORTANT!** After adjusting settings for the additional functions, turn the oscillation mode knob (1) back to the oscillation mode required (white markings), otherwise the welding process cannot start.


**Additional function - path measurement:**



1. Set the oscillation mode knob to the GREEN marking.




2. Turn the oscillation path knob and set the welding path required.




3. Turn the knob back to the white function parameter required.

**Additional function - segment welding:**



1. Set the oscillation mode knob to the YELLOW marking.




2. Set the segment welding function parameter:

**Start-up delay / flying-start:**

If start-up delay value is positive [s]: Start welding - Dwell time elapses - Carriage starts to move.

If start-up delay value is negative [s]: Carriage starts to move. The arc does not ignite until the "flying start" time has expired.



**Return travel path:**

Return time at the end of the welding path.



**Segment path with welding:**


Length of the individual welding segments.



**Segment path without welding:**

Length of the distances between the individual welding segments.


## Selecting additional functions (continued)



3. Turn the knob back to the white function parameter required.

### Saving a program


#### Before saving a program:



Set the toggle switch for the "Change direction/stop" limit switch functions to the lower position (change direction).



Set the welding mode toggle switch to the 0 position.



Set the traversing direction toggle switch to the central position 0.

#### To save a program:



- Press the travel speed knob (7) and end-crater filling time knob (11) at the same time and hold for 4 seconds.
- memX appears on the display. X stands for the program number that has not yet been selected.
- Turn the travel speed knob to select the program number required.
- Press the travel speed knob to save the program with this number.

## Loading the welding program


### NOTICE!

The remote control has a factory-saved, read-only program "mem0", which contains the working parameters for the welding carriage and oscillation unit. The value "mem0" cannot be overwritten.

To load a saved program, "mem" and the number of the last used program must be shown on the display.




Set the welding mode toggle switch to the 0 position.




Set the traversing direction toggle switch to the central position 0.



Set the change direction/stop toggle switch to the change direction position.



Press the travel speed button and the oscillation path / total welding path button at the same time for at least 4 seconds.




Turn the travel speed button to select a program.  
Press the button again to load the program.

## Changing the units of measurement

Measurements can be displayed in either metric (cm) or imperial (inch) units. To change the units, proceed as follows:



Set the main switch on the control box to 0 (off).



Press and hold the left and right dwell time buttons at the same time.



Switch on the main switch on the control box. The unit of measurement selected (cm or inch) is shown on the display.



Select the setting required using the travel speed knob.

Press the travel speed knob once to confirm and apply the setting.

# FRC-45 Pro remote control

## Safety

### **⚠️ WARNING!**

**Operating the equipment incorrectly can cause serious injury and damage.**

Do not use the functions described here until you have fully read and understood the following documents:

- These Operating Instructions
- All the Operating Instructions for the system components, especially the safety rules.

## FRC-45 Pro control elements



**(1) Touch display**

Displays welding parameters and error codes.

**(2) Quick Stop**

- Stops all movement
- stops arc and welding process
- but the power supply remains present.

**(3) Welding power selection wheel**

For regulating the preset welding power (m/min).

- The selection wheel must be pressed and turned simultaneously, in order to change the preselected value.

**IMPORTANT!** Welding power value can only be changed in main menu!

**(4) Multifunctional dial**

**Turning the button:**

- Navigates through the menu
- Changes a parameter
- Changes a parameter value

**Pressing the button:**

- Selects a menu
- Selects a parameter
- Confirms an altered parameter value

**(5) Keys F1 to F4**

Keys are freely configurable, functions can be selected in the service menu

**(6) Welding mode**


3 welding modes can be selected:

- Test
- Without arc (O)
- With arc (I)

**(7) Traversing direction**

Selects the traversing direction of the carriage: forwards or backwards

## Touch display



### (1) SERVICE menu

For loading and saving welding programs.  
The keys F1 to F4 are also individually assigned in the service menu.

### (2) CARRIAGE menu

For editing the parameters that affect the carriage.

### (3) OSC menu

For editing the oscillation parameters.

### (4) ACC menu

For editing all parameters for the ACC function (Arc Current Control).

### (5) PS menu

For editing the power source parameters.

### (6) ORBITAL menu

For editing the orbital parameters.

### (7) BACK button

Return to main menu.

### (8) Options display

Displays related options and modules, such as oscillation unit, ACC module, orbital, etc.

### (9) Status indicator

Displays an active or inactive arc, as well as the limit switches for the carriage or oscillation unit.

### (10) Carriage speed

Displays the set carriage speed.

### (11) Welding power


Displays the currently set welding power in m/min.

### (12) Wire feed speed

### (13) Display field for error messages or Quick Stop button

# Standard software functions

## Selecting a menu




Tap the desired menu button to access the menu.

The following menus are available for selection:

- Carriage
- Oscillation unit (Osc)
- ACC
- Power source (Ps)
- Orbital

## Select a welding parameter




Three parameters are always displayed at the same time.

The currently active parameter is enlarged in the centre.

To scroll either:


- Tap the blue arrows
- Scroll with the multifunctional dial
- Tap the parameter field directly and move the display

## Editing parameters



To edit a parameter either:


- Click on the parameter field
- Press once on the multifunctional dial




In editing mode, the parameter value will be displayed in blue font.

A blue slider appears.

## Editing parameters (continued)




Rough adjustment of the parameter value:  
Tap the slider and move  
as desired.



Fine adjustment of the parameter value:  
Tap the blue arrows and set the desired  
value.

## Saving parameters



To save the adjusted value either:  
- Tap the parameter field again  
- Press once on the multifunctional dial

### NOTICE!

In order to edit the oscillation parameters, the oscillation unit must be attached to the carriage.


# Service menu

## Assigning function keys

Keys F1 to F4 can be assigned with functions from the service menu.  
Follow these steps:



1. Tap the gear wheel symbol  
► The service menu will open.



2. Use the multifunctional dial to select the "Button F1 Function" parameter field.



3. Press the multifunctional dial once.



► The first parameter appears in blue font.

4. Use the multifunctional dial to select the desired parameter.




5. Press the multifunctional dial once to save the setting.




► The function key F1 has been assigned.

6. To assign keys F2 to F4, repeat steps 2 to 5.


## Selecting power source




1. Tap the gear wheel symbol  
► The service menu will open.



2. Use the multifunctional dial to select the "SELECT PS" parameter field.



3. Press the multifunctional dial once to access the list of programs.  
The slider appears.



4. To select power source:
  - either turn the multifunctional dial
  - or touch the slider and move it.



5. Press the multifunctional dial once to confirm.



## Loading welding program



1. Tap the gear wheel symbol  
► The service menu will open.



2. Use the multifunctional dial to select the "Load Program" parameter field.




3. Press the multifunctional dial once to access the list of programs.




4. Turn the multifunctional dial and select the desired program number.



5. Press the multifunctional dial once to confirm.



## Saving welding program



1. Tap the gear wheel symbol  
► The service menu will open.



2. Use the multifunctional dial to select the "Save Program" parameter field.



3. Press the multifunctional dial once.



► The next free program number is displayed.

4. Press the multifunctional dial once to save the welding program.




## Selecting the language

The FRC-45 Pro remote control makes it possible for the operator to choose between four languages:

- German
- English
- French
- Spanish

To change the language, proceed as follows:



1. Tap the gear wheel symbol  
► The service menu will open.

## Selecting the language (continued)



2. Use the multifunctional dial to select the "Select Language" parameter field.



3. Press the multifunctional dial once.



► The language line is displayed in blue. A blue slider appears.

4. Use the multifunctional dial to select the required language.




5. Press the multifunctional dial once to confirm.




## Changing the units of measurement

Measurements can be displayed in either metric (cm) or imperial (inch) units. To change the units, proceed as follows:



1. Tap the gear wheel symbol  
► The service menu will open.




2. Use the multifunctional dial to select the "Select Units" parameter field.




3. Press the multifunctional dial once.



► The unit indication is displayed in blue. A blue slider appears.



4. Use the multifunctional dial to select the required unit of measurement.




5. Press the multifunctional dial once to confirm.



# Menu description

## CARRIAGE menu




Press the CARRIAGE menu button to access these parameters.

### The following parameters are available:

Travel Speed	Regulates the travel speed of the welding carriage. Display in [cm/min].
Total Path	Total welding path in [cm]. Once this distance has been reached, the welding process will stop automatically. The total path can be divided into several segments.
Welding Width	Segment length in [cm].
Segment Gap	Segment space in [cm].
Back Filling	The path in which the carriage travels in the opposite direction to fill the end-crater. Information in [s].
Start Delay	Defines the time between ignition of the arc and commencement of carriage movement. Setting range: 0 to +5 s
Flying Start	Defines the time between the commencement of carriage movement and ignition of the arc. Setting range: 0 to -5 s
End Crater Filling	Enables the weld seam to be finished smoothly. Information in [s].
Return Travel	Limit switch function, change direction / stop: According to the settings, the carriage will have the following response when the limit switch is reached: <ul style="list-style-type: none"><li>- Carriage stops</li><li>- Carriage changes direction and continues moving.</li></ul>

## OSC menu




Press the OSC menu button to access these parameters.

### The following parameters are available:

Oscillation Speed	Regulates the oscillation speed. - When using the linear oscillation unit: Display in [cm/min] - When using the radial oscillation unit: Display in [%]
Oscillation Path	Regulates the oscillation path. - When using the linear oscillation unit: Display in [cm/min] - When using the radial oscillation unit: Display in [%]
Dwell time Left	Regulates the oscillation dwell time on the left. Displayed in [s].
Dwell time Middle	Regulates the oscillation dwell time in the middle of the oscillation motion. Displayed in [s].
Dwell time Right	Regulates the oscillation dwell time on the right. Displayed in [s].
Oscillation Mode	Oscillation mode. Four oscillation modes can be selected: - No oscillation - Trapezoidal oscillation - Triangular oscillation - Rectangular oscillation
Offset	Regulates the offset during oscillation.

## ACC menu



Press the ACC menu button to access these parameters.

**IMPORTANT!** For a detailed description of the ACC function, see the chapter entitled "ACC FUNCTION".

## PS menu (Power Source)




Press the PS menu button to access these parameters.

### The following parameters are available:

Wire feed speed	Wire feed speed in m/min
Gas Test	To check the gas flow before starting a welding process.
Wire Inchig	Feeds the wire
Wire Retract	Retracts the wire
Arc Length Correction	For correcting the arc length.
Dynamic correction	For influencing the short-circuiting dynamic at the instant of droplet transfer. Setting range: -10 - +10 Factory setting: 0 - Harder, more stable arc 0 Neutral arc + Soft, low-spatter arc
Job number:	The following working modes can be selected: 0 Manual mode 1 Remote Controller (Special 2 Step) 2 Job mode 3 (not used) 4 Manual mode 5 Manual mode 6 Manual mode 7 Job mode manual (TPSi) 8 Remote controller (2Step)

## ORBITAL menu



Press the ORBITAL menu button to access these parameters.

For a detailed description of the orbital function, see the chapter entitled "ORBITAL FUNCTION".

# ACC function

## General


ACC = Arc Current Control.

The FMS 100 or FMS 50 slide with ACC function communicates with the power source's system interface and controls the exact torch distance from the workpiece. The Fronius CANOpen i-kit, item number 4,100,251, is also required.

**IMPORTANT!** The FMS slide with ACC function can be used with the TPS and TPSi power sources. The ACC function only works with steel components, not with aluminium materials.

When using the TPSi including PMC and LSC, the **penetration stabilizer** and **arc stabilizer** functions must be disabled.

## Activating the ACC function: FRC-45 Basic remote control




Turn the selector switch on the remote control to the ACC position.

Once the selector switch has been turned to the ACC position, only the following buttons are active:

### OFFSET button

#### When using without an oscillation unit:

Turning the button: manually positions the welding torch.



#### When using the linear oscillation unit:


Turning the button: Manually positions the welding torch.

Pressing the button: Calibrates the distance between the welding torch and the workpiece.

Pressing the button once and turning: Offsets oscillation unit

Pressing the button twice and turning: ACC setting (up / down)


### TRAVEL SPEED button



Used in ACC mode for the following functions:

- Selecting the welding parameters
- Changing the value of a parameter
- Confirming the selected value

## Activating the ACC function: FRC-45 Pro remote control




1. Tap the ACC menu button on the touchscreen.



2. Tap the parameter field or press the multifunctional dial once.
  - ▶ The ACC ACTIV ON / OFF parameter is displayed.



- ▶ The OFF parameter is displayed in blue.
- ▶ A button is displayed.




3. To switch to ON either:
  - Touch the button
  - Turn the multifunctional dial
  - Tap the right blue arrow
  - ▶ The button is highlighted in blue, the display changes to ON.

4. To confirm the selection either:
  - Tap the parameter field again
  - Press the multifunctional dial once

## ACC parameter

### FRC-45 Basic

ON / OFF





### FRC-45 Pro



For activating / deactivating the ACC function.



### S / Sensitivity



This parameter indicates the sensitivity of the ACC function. The pre-set standard value is 5. The values are adjustable from 1 to 9. The smaller the value, the more sensitive and the quicker the reaction.

**IMPORTANT!** If the sensitivity is adjusted too high, this could result in interruptions to the welding process.

### T / Target Timeout (dwell time in seconds)




Dwell time after the start of welding, before the ACC module assumes and saves the value for the arc amperage.

The pre-set standard value is 8, but adjustments can be made between 1 and 60 seconds.

### Offset

(No screen on the  
FRC-45 Basic)




Parameter for the offset movement of the welding torch during the welding process.

# ORBITAL function

## General

ORBITAL mode is used to set the parameters for welding a pipe.  
The Fronius CANOpen i-kit, item number 4,100,251, is also required.


## Activating ORBITAL function: FRC-45 Basic remote control



Turn the selector switch on the remote control to the ORBITAL position.

Once the selector switch has been turned to the ORBITAL position, only the following buttons are active:


### TRAVEL SPEED button



Used in ORBITAL mode for the following functions:

- Selecting the welding parameters
- Changing the value of a parameter
- Confirming the selected value

**Activating  
ORBITAL  
function:  
FRC-45 Pro  
remote control**



1. Tap the ORBITAL menu button on the touchscreen.

► The ORBITAL ACTIV ON / OFF parameter is displayed.

2. Tap the parameter field or press the multifunctional dial once.

► The OFF parameter is displayed in blue.  
► A button is displayed.


3. To switch to ON either:
    - Touch the button
    - Turn the multifunctional dial
    - Tap the right blue arrow
- The button is highlighted in blue, the display changes to ON.

4. To confirm the selection either:
  - Tap the parameter field again
  - Press the multifunctional dial once


## Orbital parameters

### FRC-45 Basic

ON / OFF




### FRC-45 Pro





For activating / deactivating the ORBITAL function.

### Actual Position (position of the carriage)





Displays the position of the carriage in relation to the current workpiece.  
The display ranges from 0° to 360°. This parameter is only for informational purposes and cannot be altered.

### R / Ring Diameter



Shows the diameter of the currently used ring-shaped rail in cm.

### P / Pipe Diameter




Shows the current workpiece diameter in cm.  
Both the parameters R and P are used to calculate the welding speed.  
**IMPORTANT!** If one of these two parameters is set at 0, a straight welding movement will be calculated instead of a round one.

**Orbital  
parameters**  
(continued)

**FRC-45 Basic**      **FRC-45 Pro**

**A / Total Path**



Shows the entire welding path in degrees. The maximum value is 900°, which is equal to 2.5 journeys around the workpiece.

## Segment parameters



The segment welding function is for welding a round workpiece in up to 16 different segments.

That means that the total welding path A is divided into segments.

**IMPORTANT!** The following three steps always refer to a single segment.  
In the example shown, a segment is welded from 0° to 90° as JOB 1 with a welding speed of 40 cm/min.

### FRC-45 Basic


#### Step 1: End point of the first segment



Indicates the end point of the first segment.

Example: Input 90° - the welding torch welds from 0° to 90°.



#### Step 2: Job selection



Selection of jobs for welding the first segment.

Once the end point for the first segment has been reached, the carriage control switches to the job that has been pre-set for segment 2.

#### Step 3: Welding speed



Displays the pre-set welding speed for the currently selected segment.

# Starting welding: FRC-45 Basic

## Switching on system components

### WARNING!

#### Danger of injury from premature arc ignition.

The arc may be ignited accidentally. This can cause serious eye injuries.

- Before switching on the system components, ensure that the "Welding mode" toggle switch on the welding carriage remote control is set to the "O" position.

**IMPORTANT!** The following switch-on sequence of the system components must be strictly adhered to:

- Switch on the power source and let it completely start up
- Switch on wire feeder (if no supply via power source)

After the power source is fully powered up:

- Switch on the FlexTrack control box

## Working with or without an oscillation unit

The welding carriage can work with and without oscillation (linear or radial). If the oscillation unit is not required, it should be removed according to the instructions in the "Preparing the carriage" section under "Replacing the oscillation unit with an adjustment unit".

After the control box has been switched on, it automatically checks whether the linear or radial oscillation unit is connected, and the current status appears on the display.

Linear oscillation unit is connected: Oscillation speed and oscillation path are displayed in [cm/min].

Radial oscillation unit is connected: Oscillation speed and oscillation path are displayed in [%].

## Performing a test run

Perform a test run to check that all system components are working together correctly. The test run is carried out without an arc and allows you to check all the movements during the program sequence.



Set the WELDING MODE toggle switch to the 0 position.




Move the TRAVERSING DIRECTION toggle switch forwards. The carriage moves according to the programmed parameters, but no welding is performed. The carriage's current speed is then shown on the display. All parameters can be changed during operation.

## Performing a test run

(continued)

When the carriage reaches the limit switch:



If the CHANGE DIRECTION/STOP toggle switch is forwards:

- ▶ The carriage stops when it triggers the limit switch.



If the toggle switch is in the CHANGE DIRECTION position:


- ▶ After triggering the limit switch, only the oscillation unit stops, and the welding carriage starts to move back in the opposite direction. In this situation, the travel speed can be increased to the maximum for the return journey: press the travel speed knob and hold for 2 seconds.

### NOTICE!


**NOTE!** If the TRAVERSING DIRECTION toggle switch is in the central position and the WELDING MODE toggle switch is in the TEST position, this position causes the arc to light up briefly.

Activating the welding function: Set the WELDING MODE toggle switch to the "I" position.


## Starting the welding process



Set the WELDING MODE toggle switch to the "I" position.



Set the CHANGE DIRECTION/STOP toggle switch to the position required.



Set the TRAVERSING DIRECTION toggle switch to the position required (forwards or backwards). The welding process starts.

**IMPORTANT!** Never leave the device unattended during the welding process.



To stop the carriage early, move the TRAVERSING DIRECTION toggle switch to the central position.

# Starting welding: FRC-45 Pro

## Switching on system components

### **⚠️ WARNING!**

#### Danger of injury from premature arc ignition.

The arc may be ignited accidentally. This can cause serious eye injuries.

- Before switching on the system components, ensure that the "Welding mode" toggle switch on the welding carriage remote control is set to the "O" position.

**IMPORTANT!** The following switch-on sequence of the system components must be strictly adhered to:

- Switch on the power source and let it completely start up
- Switch on wire feeder (if no supply via power source)

After the power source is fully powered up:

- Switch on the FlexTrack control box

## Working with or without an oscillation unit

The welding carriage can work with and without oscillation (linear or radial). If the oscillation unit is not required, it should be removed according to the instructions in the "Preparing the carriage" section under "Replacing the oscillation unit with an adjustment unit".

After the control box has been switched on, it automatically checks whether the linear or radial oscillation unit is connected, and the current status appears on the display.

Linear oscillation unit is connected: Oscillation speed and oscillation path are displayed in [cm/min].


Radial oscillation unit is connected: Oscillation speed and oscillation path are displayed in [%].

## Performing a test run

Perform a test run to check that all system components are working together correctly. The test run is carried out without an arc and allows you to check all the movements during the program sequence.



Set the WELDING MODE toggle switch to the 0 position.



Move the TRAVERSING DIRECTION toggle switch forwards.  
The carriage moves according to the programmed parameters, but no welding is performed.  
The carriage's current speed is then shown on the display. All parameters can be changed during operation.

## Starting the welding process



Set the WELDING MODE toggle switch to the "I" position.



Set the TRAVERSING DIRECTION toggle switch to the position required (forwards or backwards). The welding process starts.

**IMPORTANT!** Never leave the device unattended during the welding process.

To stop the carriage early, move the TRAVERSING DIRECTION toggle switch to the central position.

# **Maintenance and disposal**



# Troubleshooting

<b>General</b>	In the event of faults, note that the functioning of the entire system depends on many additional components (power source, wirefeeder, etc.) that are also potential sources of problems. If an error occurs, "Err" and the error number are shown on the display.
<b>Basic requirements for the system to work</b>	<ul style="list-style-type: none"><li>▶ Connections have been established between the separate system components</li><li>▶ System components are supplied with electricity and the mains voltage for each component complies with the rating plate.</li></ul>
<b>Event codes</b> <b>Remote control</b> <b>FRC-45 Basic</b>	 <p>The event codes are displayed as letter and number combinations.</p>
<b>FRC-45 Pro remote control event codes</b>	 <p>The event codes are displayed as symbols on the main screen.</p>

**FRC-45 Pro  
remote control  
event codes**  
(continued)

Display	Description	Remedy
	Welding carriage has reached one of the contact cams on the rail.	Release the limit switch using the traversing direction toggle switch
	The oscillation arm has reached a limit position.	Release the limit switch using the offset knob.
	Status display WITH / WITHOUT WELDING	--
	Display cm / min or inch / min. This value is displayed on the main screen next to the travel speed.	To change the setting: see the "FRC-45 Pro remote control" section under "Changing the units of measurement".

**Error code  
display**


**FRC-45 Basic**

Error codes are numbered and displayed with ERR and the relevant error number.



**FRC-45 Pro**

The error code is displayed as plain text in the header of the main screen, along with a short description.



**Error codes**

Display	Description	Remedy
err1 Error 1	Error during initiation of the CAN communication system.	Rectify short circuit between the lines or communication ports.
err2 Error 2	Communication error between carriage and remote control.	Check connections, tighten if necessary.
err3 Error 3	Communication error between remote control and oscillation unit.	If necessary, replace damaged control lines.
err4 Error 4	Communication error between remote control and control box.	Contact your FRONIUS service technician.
err5 Error 5	Error while saving or reading, memory error on the remote control.	Contact your FRONIUS service technician.
err6 Error 6	Operating temperature exceeded or ambient temperature too high.	Allow device to cool down. Operate in a lower ambient temperature.
err7 Error 7	Error in motor control unit.	Contact your FRONIUS service technician.
err8 Error 8	Error in oscillation control unit.	Contact your FRONIUS service technician.
err9 Error 9	Error in the control unit in the control box.	Contact your FRONIUS service technician.

**Error codes**  
(continued)

<b>Display</b>	<b>Description</b>	<b>Remedy</b>
Err 10 Error 10	Error while the display is starting up.	Contact your FRONIUS service technician.
Err 11 Error 11	Communication error between ACC module and remote control.	Check connections; if necessary, tighten screw fittings. If necessary, replace defective connection lines.
Err 12 Error 12	Error in the ACC module.	Contact your FRONIUS service technician.
Err 13 Error 13	Communications error between the CANopen robot interface module installation kit and the remote control.	Check connections; if necessary, tighten screw fittings. If necessary, replace defective connection lines.
Err 14 Error 14	Error in the CANopen robot interface module installation kit.	Contact your FRONIUS service technician.

# Maintenance

## Maintenance personnel



### WARNING!

#### Risk of injury and damage from incorrectly performed maintenance work.

It is essential to adhere to the maintenance intervals and maintenance procedures. The manufacturer accepts no liability for any damage caused by inadequate or poorly performed maintenance.

- All maintenance work on the welding carriage must be carried out by trained technicians.

#### Electrically skilled person (electrician):

Person who, due to specialist training, knowledge and experience of the relevant regulations, is able to evaluate the tasks assigned to him/her and to identify and avoid potential hazards.

#### Electrically instructed person:

Person adequately advised or supervised by skilled persons to enable him or her to perceive risks and to avoid hazards which electricity can create and to understand the necessary safety precautions and protection devices.

Note: Instruction must be recorded in writing.

#### Electrical layperson:

Someone who is neither a skilled person nor an instructed person.

## Maintenance record

The following measures regarding maintenance must be put in place by the plant operator:

- a service book containing the required information (date, operator, maintenance work carried out) must be kept.

## Recommended lubricants

**IMPORTANT!** Lubricants with solid lubricant additives (e.g.: MoS<sub>2</sub>, graphite and PTFE) are not suitable for guiding systems.

Lubricant	DIN	DIN number	Comment
Grease	KP 2-K	51502 / 51825	Lithium soap grease
Lubricating oil	CLP32-100	51517 Part 3	ISO VG 32-100

**NOTICE!**

Use a dry cleaning cloth to clean the machine components. Only use a cleaning agent if this is indicated in the maintenance procedure for a specific part.

Item	Component	Measure	Interval
A	Linear guides	Clean, check oil film	M
B	Gearbox	Clean, regrease	M
C	Rack and pinion	Clean, regrease	M
D	Rollers, underbody & rails	Clean, check position	M
E	Safety devices: - Limit switch	Function test	D
F	Grease nipples	Regrease	M
G	Connection contacts	Clean	W

D Daily                            1/2 Y Half-yearly

W Weekly                            Y Annually


M Monthly

**Daily care:**


After every use:

- Remove the welding carriage from the guide rail.
- Using a brush or a soft cloth, clean the guide rails for the oscillation unit, the guide rollers and the gearbox.
- Carry out maintenance work as shown in the illustration below.

**IMPORTANT!** Do not use compressed air.



**Maintenance  
intervals and  
procedures**  
(continued)



**Clean and lubricate the gearbox wheel:**

**IMPORTANT!** The gearbox must be cleaned and lubricated once a month (B):

1. Clean the gear wheel with a brush
2. Lubricate with grease


**Maintain the bottom of the carriage:**

Clean the guide rollers (D)

### Maintenance on the linear oscillation unit

**IMPORTANT!** The toothed rack on the oscillation unit must be lubricated once a month.

The guide rail must be lubricated every six months.



1. Fully extend the oscillation arm.
2. Undo the four M5 screws (a) and remove the guide rail cover.
3. Clean the linear guide with a brush (A).
4. Lubricate the linear guide on the side of the oscillation unit housing.
5. Add approximately 2 g of lubricant to the grease cup via the Ø 12 mm grease nipple (F).

### Maintenance on the radial oscillation unit

#### Daily:

Clean the oscillation unit after use, remove any welding spatter or smoke residue.

#### Every two years:

If necessary, top up the gear grease.

### Maintenance of the FMS slides

#### Daily:

Clean the FMS slide after use, remove any welding spatter or smoke residue.

#### Every six months:



Regrease guides.

## Adjusting the gear rack play



1. Loosen the three motor bolts (marked in green in the image) using a 2.5 mm Allen key.  
**IMPORTANT!** Only loosen them, DO NOT unscrew them completely.

2. Move the arm of the oscillation gently forwards and backwards to find the largest gap between the gear and the gear rack.  
This is important so that the motor can move down to the lowest possible position in the next step.



3. Tighten the three bolts slightly using the 2.5 mm Allen key.
4. Insert the Allen key into the socket of the top bolt and tap it carefully using a hammer.
5. Repeat this process with the bottom two bolts.
6. Fully tighten the bolts.

7. Alternative: tighten the three bolts slightly.  
Hit the bottom of the oscillation on a flat surface so the gravitational force causes the motor to move down.

# **Technical data**



# Technical data

## FlexTrack 45 PRO Carriage

Welding position	PA, PB, PC, PF, PG
Material thickness	min. 4 mm (min. 0.15 in.)
Horizontal traversing speed	5 - 300 cm/min (1.96 - 118.11 in.)
Vertical traversing speed	5 - 250 cm/min (1.96 - 98.42 in.)
End-crater filling time	0 - 5 seconds
Max. load, horizontal/vertical	45 / 30 kg (99.20 / 66.13 lb)
Weight (without torch holder)	8.5 kg (18.74 lb)
Protection class	IP 23

## Control box

Mains voltage 50 - 60 Hz	115/230 V
Supply voltage	24 V DC
Weight (without cables)	4.6 kg (10.15 lb)
Protection class	IP 23

## FRC-45 Basic and FRC-45 Pro

Cable length	10 m (393.70 in.)
Weight (without cables)	1.5 kg (3.30 lb)
Protection class	IP23
Operating temperature	0 – 50°C

## Linear oscillation unit

Oscillation speed	5 - 400 cm/min (1.97 - 157.48 in/min)
Oscillation path	2 - 30 mm (0.079 - 1.2 in.)
Offset	0 - 50 mm (0 - 2 in.)
Dwell time	0 - 3 seconds
Weight (without torch holder)	3.2 kg (7.05 lb)
Protection class	IP 23

## Radial oscillation unit

Oscillation speed (at 150 mm radius)	20 - 120 cm/min (7.78 - 47.24 in.)
Oscillation path (at 150 mm radius)	1 - 30 mm (0.039 - 1.18 in.)
Offset	0 - 50 mm (0 - 1.97 in.)
Dwell time	0 - 3 seconds
Weight (with torch holder)	3.6 kg (7.94 lb)
Protection class	IP 23

**FMS 100/  
ML15/SE/ACC  
(optional)**

Max. load capacity	15 kg (33.06 lb)
Control voltage	24 VDC
Power consumption	8 W
Traversing speed (automatic mode)	30 cm / min (11.8 in)
Traversing speed (manual mode)	max. 1 m / min (39.37 in)
Travel path	0.5 - 100 mm (0.01 - 3.93 in.)
Degrees of sensitivity	1-9
Dwell time	1 - 60 s
Degree of protection	IP 23
Unladen weight	2.45 kg (5.40 lbs)

**IMPORTANT!** The ACC module may only be used with the TPS power source.

**FMS 50/ML15/SE/  
ACC (optional)**

Max. load capacity	15 kg (33.06 lb)
Control voltage	24 VDC
Power consumption	8 W
Traversing speed (automatic mode)	30 cm / min (11.8 in)
Traversing speed (manual mode)	max. 1 m / min (39.37 in)
Travel path	max. 50 mm (1.96 in.)
Degrees of sensitivity	1-9
Dwell time	1-60s
Degree of protection	IP 23
Unladen weight	2 kg (4.40 lb)

**IMPORTANT!** The ACC module may only be used with the TPS power source.

**Environmental  
conditions**



Operation or storage of the carriage outside the stipulated area will be deemed as improper use. The manufacturer shall not be held liable for any damage arising from such usage.

Ambient air temperature range:

- during operation: +0°C to +50°C (32°F to 122°F)
- during transport and storage: -20 °C to +55 °C (-4 °F to 131 °F)

Relative humidity:

- up to 50% at 40 °C (104 °F)
- up to 90% at 20 °C (68 °F)

Keep ambient air free from dust, acids, corrosive gases and substances, etc.

Can be used at altitudes of up to 2000 m (6561 ft. 8.16 in.)

**Noise data**




When used for its intended purpose, the machine generates a maximum sound power level of > 80 dB(A) (ref. 1pW) as measured according to EN ISO 11201.

It is not possible to provide an exact emission value as this is influenced by both the process and the environment, depending on:

- the welding process (MIG/MAG, TIG welding)
- the type of power selected (DC or AC)
- the power range
- the type of weld metal
- the resonance characteristics of the workpiece
- the workplace environment, etc.

► Wear ear protection to reduce the harmful effects of noise.

## Dimensions




### Dimensions with linear oscillation unit

A (with oscillation unit)	469 - 556 mm
(without oscillation unit)	452 - 542 mm
B (with oscillation unit)	56 - 240 mm
(without oscillation unit)	80 - 263 mm
C (with oscillation unit)	357 mm
(without oscillation unit)	342 mm
D (with oscillation unit)	239 mm
(without oscillation unit)	270 mm
E (overall height with straight, rigid rails)	313 mm
F (overall height with magnetic bridge)	310 - 408 mm
G (overall height with adjustable foot bridge)	310 - 408 mm

### Dimensions with radial oscillation unit

H (with oscillation unit)	543 - 653 mm
(without oscillation unit)	452 - 542 mm
I (with oscillation unit)	191 - 311 mm
(without oscillation unit)	80 - 263 mm
J (with oscillation unit)	243 - 363 mm

## FMS slide dimensions



## FMS slide dimensions

A	124 mm (4.88 in.)
B	308 mm (12.13 in.)
C	203 mm (7.99 in.)
D	54 mm (2.13 in.)
E	111 mm (4.37 in.)
F	50 mm (1.97 in.)
G	50 mm (1.97 in.)


## Weights of rails and bridges

Magnetic bridge	2.5 kg (5.5 lb)
Vacuum bridge	1.6 kg (3.5 lb)
Magnetic bridge with spacers	2.7 kg (5.9 lb)
Vacuum bridge with spacers	1.8 kg (3.9 lb)
Magnetic bridge with spacer and metric adjustment unit	3.4 kg (7.4 lb)
Magnetic bridge with metric adjustment unit	3.2 kg (7.05 lb)
Bridge with adjustable foot, spacer and metric adjustment unit	1.5 kg (3.3 lb)
Bridge with adjustable foot and metric adjustment unit	1.3 kg (2.8 lb)
Vacuum bridge with spacer and metric adjustment unit	2.6 kg (5.7 lb)
Vacuum bridge with metric adjustment unit	2.4 kg (5.2 lb)
Rigid guide rail 1884 mm	11 kg (24.3 lb)
Flexible guide rail 1884 mm	5.5 kg (12.1 lb)
Flexible guide rail 1695 mm	4.8 kg (10.5 lb)
Flexible guide rail 1130 mm	3.3 kg (7.2 lb)
Rigid ring rail Ø200-300 mm	8.8 kg (19.4 lb)
Rigid ring rail Ø300-480 mm	11 kg (24.3 lb)
Rigid ring rail Ø480-660 mm	14 kg (30.8 lb)
Rigid ring rail Ø660-840 mm	16 kg (35.3 lb)
Rail segment Ø840-1020 mm	19 kg (41.8 lb)
Rail segment Ø1020-1200 mm	22 kg (48.5 lb)
Rail segment Ø1200-1380 mm	24 kg (52.9 lb)
Rail segment Ø1380-1560 mm	27 kg (59.5 lb)

## Rating plates

### NOTICE!


The rating plates may not be removed or modified without the consent of Fronius International GmbH. Ensure that the rating plates remain legible.




Rating plate, welding carriage

<b>Fronius</b>		E-Cabinet	
		Art.No.: 48,0005,2560	
YC:2018		U <sub>1</sub>	U <sub>2</sub>
 1~ 50/60 Hz		115/230 VAC	24 VDC
		I <sub>1</sub>	weight
		4 A	4,6 kg
<b>CE</b>		IP23	  


Rating plate, control box




Rating plate, BASIC remote control




Rating plate, PRO remote control




Rating plate, linear oscillation unit



Rating plate, radial oscillation unit



Rating plate, FMS 50



Rating plate, FMS 100

All illustrations of rating plates are representative images.

## Ring rail settings table

**IMPORTANT!** A quick-reference summary of the settings table, showing the most important settings, can be found on the inside of the transport box lid.

$\varnothing$ Round guide rail [mm]	$\varnothing$ Workpiece Dp [mm]	Min. $\varnothing$ for bridges with spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges with spacer block Dp <sub>max</sub> [mm]	Min. $\varnothing$ for bridges without spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges without spacer block Dp <sub>max</sub> [mm]	Number bridges Dp <sub>max</sub> [mm]	Distance M on adjustment unit	$V_{carriage} = D_{rail} * V_w / D_{workpiece}$ [cm/min] $V_w = welding speed [cm/min]$
200-300	200-300	192	308	412	376	492	3	196-0.5•Dp 537*Vw/Dp
300-480	300-400	296	412	376	492	4	245-0.5•Dp 285-0.5•Dp 718*Vw/Dp	
480-660	480-580	476	592	556	672	6	335-0.5•Dp 375-0.5•Dp 900*Vw/Dp	
660-840	660-760	655	771	735	851	8	425-0.5•Dp 465-0.5•Dp 1080*Vw/Dp	
840-1020	840-940	835	951	915	1031	9	515-0.5•Dp 555-0.5•Dp 1260*Vw/Dp	
1020-1200	1020-1120	1015	1131	1095	1211	12	605-0.5•Dp 645-0.5•Dp 1440*Vw/Dp	
1200-1380	1200-1300	1195	1311	1275	1391	15	695-0.5•Dp 735-0.5•Dp 1620*Vw/Dp	
1380-1560	1380-1480	1375	1491	1455	1571	16	785-0.5•Dp 825-0.5•Dp 1800*Vw/Dp	

## Flexible rail segments settings table

$\varnothing$ Round guide rail [mm]	$\varnothing$ Workpiece Dp [mm]	Min. $\varnothing$ for bridges with spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges with spacer block Dp <sub>max</sub> [mm]	Min. $\varnothing$ for bridges without spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges without spacer block Dp <sub>max</sub> [mm]	Number bridges	Distance M on the adjustment unit	$V_{carriage} = D_{rail} * V_w / D_{workpiece}$ [cm/min]	$V_w = welding speed [cm/min]$
1560-1740	1560-1660	1555	1671	1635	1751	18	875-0.5*Dp	1980*Dp/Vw	Dp/Vw
1740-1920	1640-1740	1735	1851	1815	1931	18	915-0.5*Dp	1980*Dp/Vw	Dp/Vw
1920-2100	1740-1840	1820-1920	2031	1995	2111	20	1005-0.5*Dp	2160*Dp/Vw	Dp/Vw
2100-2280	1820-1920	2095	2211	2175	2291	21	1055-0.5*Dp	2340*Dp/Vw	Dp/Vw
2280-2460	1920-2020	2275	2391	2355	2471	25	1145-0.5*Dp	2520*Dp/Vw	Dp/Vw
2460-2640	2000-2100	2455	2570	2535	2651	25	1235-0.5*Dp	2700*Dp/Vw	Dp/Vw
2640-2820	2100-2200	2634	2750	2714	2830	28	1325-0.5*Dp	2880*Dp/Vw	Dp/Vw
2820-3000	2180-2280	2814	2930	2894	3010	30	1415-0.5*Dp	3060*Dp/Vw	Dp/Vw
3000-3180	2280-2380	2994	3110	3074	3190	30	1505-0.5*Dp	3240*Dp/Vw	Dp/Vw
3180-3360	2360-2460	3174	3290	3254	3370	30	1545-0.5*Dp	3420*Dp/Vw	Dp/Vw
3360-3540	2460-2560	3354	3470	3434	3550	33	1685-0.5*Dp	3600*Dp/Vw	Dp/Vw
3540-3720	2540-2640	3534	3650	3614	3730	33	1725-0.5*Dp	3780*Dp/Vw	Dp/Vw
3720-3900	2640-2740	3714	3830	3794	3910	35	1864-0.5*Dp	3960*Dp/Vw	Dp/Vw
3900-4080	2720-2820	3894	4010	3974	4090	36	1904-0.5*Dp	4140*Dp/Vw	Dp/Vw

**Flexible rail segments settings table (continued)**

$\varnothing$ Round guide rail [mm]	$\varnothing$ Workpiece Dp [mm]	Min. $\varnothing$ for bridges with spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges with spacer block Dp <sub>max</sub> [mm]	Min. $\varnothing$ for bridges without spacer block Dp <sub>min</sub> [mm]	Max. $\varnothing$ for bridges without spacer block Dp <sub>max</sub> [mm]	Number bridges	Distance M on the adjustment unit	$V_{carriage} = D_{rail} * V_w / D_{workpiece}$ [cm/min]	$V_w = welding speed [cm/min]$
4080-4260	4080-4180	4074	4190	4154	4270	38	2134-0.5*Dp	4500*Dp	4500*Dp
4160-4260	4160-4260	4254	4370	4334	4450	40	2174-0.5*Dp	2224-0.5*Dp	2224-0.5*Dp
4260-4360	4260-4360	4340	4440	4440	4550	41	2264-0.5*Dp	4680*Dp	4680*Dp
4440-4540	4440-4540	4520	4620	4514	4630		2314-0.5*Dp	4860*Dp	4860*Dp
4620-4720	4620-4720	4613	4729	4693	4809	43	2404-0.5*Dp	5040*Dp	5040*Dp
4700-4800	4700-4800	4793	4909	4873	4989	45	2444-0.5*Dp	5220*Dp	5220*Dp
4800-4980	4800-4980	4973	5089	5053	5169	45	2494-0.5*Dp	5400*Dp	5400*Dp
4980-5160	4980-5080	5153	5269	5233	5349	48	2624-0.5*Dp	5580*Dp	5580*Dp
5160-5340	5240-5340	5333	5449	5413	5529	48	2764-0.5*Dp	5760*Dp	5760*Dp
5340-5520	5420-5520	5513	5629	5593	5709	50	2854-0.5*Dp	5940*Dp	5940*Dp
5520-5700	5600-5700	5693	5809	5773	5889	51	2944-0.5*Dp	6120*Dp	6120*Dp
5700-5880	5700-5880	5880	5989	5953	6069	53	3034-0.5*Dp	6300*Dp	6300*Dp
5880-6060	5960-6060								

# **Spare parts, Circuit Diagram**



# Spare parts

## Spare parts, wearing parts and auxiliary materials

Using spare parts and wearing parts from third-party manufacturers may pose risks. Use approved Fronius original spare parts only.

The manufacturer cannot accept any liability for damage resulting from the use of spare or wearing parts or auxiliary materials that are not approved by the manufacturer.

## Details required when placing orders

### NOTICE!

Only trained technicians may change parts and may only do so after having read the installation and dismantling instructions supplied.

When ordering spare parts, you should provide the following data:

- Item number as per Spare Parts List
- Model name of the device
- Serial number of the device (shown on the rating plate)

**Carriage and accessories:**

8,045,639	FlexTrack 45 Pro
48,0005,2614	Control box
8,045,641	FGU 8/SD80-28
8,045,640	FOU 30/ML10
8,045,590	FOU 30/ML6/radial
8,045,581	FGU 9/SD28
8,046,044	FRC-45 Basic
8,046,043	FRC-45 Pro
8,100,224	I-kit actuating cam
8,045,599	FMS 100/ML15/SE/ACC
8,045,618	FMS 50/ML15/SE/ACC
48,0005,1752	FTH 18/D16-25
48,0005,1753	FTH 19/D22-35
48,0005,1776	FTH 18
48,0005,1777	FTH 21

**Connection cable:**


38,0100,0433	Remote control cable Remote control cable: male plug: 48,0005,2086 Remote control cable: female plug: 48,0005,2087 Remote control cable strain-relief device: 48,0005,2191
38,0100,0459	FMS connection cable 0.8 m
38,0100,0457	CANopen connection cable 5 m
38,0100,0458	Y-splitter, 2-way, 0.3 m
48,0005,2839	Control box connection cable – power source, straight plug, 10 m
48,0005,1850	Control box connection cable – power source, straight plug, 20 m

## Rails, bridges and ring rails for variable workpiece diameters:


48,0005,1754	Rail, straight 1884 mm	(74.17 inch)	incl. joining elements
48,0005,1755	Magnetic bridge /1		
48,0005,1756	Rail, flexible 1130 mm	(44.49 inch)	incl. joining elements
48,0005,1757	Rail, flexible 1695 mm	(66.73 inch)	incl. joining elements
48,0005,1758	Rail, flexible 1884 mm	(74.17 inch)	incl. joining elements
48,0005,1759	Magnetic bridge /2		
48,0005,1760	Ring rail, rigid 200-300 mm	(7.87 - 11.81 inch)	
48,0005,1761	Ring rail, rigid 300-480 mm	(11.81 - 18.89 inch)	
48,0005,1762	Ring rail, rigid 480-660 mm	(18.89 - 25.98 inch)	
48,0005,1763	Ring rail, rigid 660-840 mm	(25.98 - 33.07 inch)	
48,0005,1764	Point support, adjustable		
48,0005,1765	Ring rail, rigid 840-1020 mm	(33.07 - 40.15 inch)	
48,0005,1766	Ring rail, rigid 1020-1200 mm	(40.15 - 47.24 inch)	
48,0005,1767	Ring rail, rigid 1200-1380 mm	(47.24 - 54.33 inch)	
48,0005,1768	Ring rail, rigid 1380-1560 mm	(54.33 - 61.41 inch)	
48,0005,1769	Magnetic bridge, adjustable /1		
48,0005,1770	Magnetic bridge, adjustable /2		
48,0005,1771	Vacuum bridge		
48,0005,1792	Vacuum bridge with support		
48,0005,1793	Point support, adjustable /2		


## Ring rail for defined workpiece diameters:

48,0005,2511	Ring rail 254 mm (10 inch)	48,0005,2529	Ring rail 1168.4 mm (46 inch)
48,0005,2512	Ring rail 304.8 mm (12 inch)	48,0005,2530	Ring rail 1219.2 mm (48 inch)
48,0005,2513	Ring rail 355.6 mm (14 inch)	48,0005,2531	Ring rail 1270 mm (50 inch)
48,0005,2514	Ring rail 406.4 mm (16 inch)	48,0005,2532	Ring rail 1320.8 mm (52 inch)
48,0005,2515	Ring rail 457.2 mm (18 inch)	48,0005,2535	Ring rail 1371.6 mm (54 inch)
48,0005,2516	Ring rail 508 mm (20 inch)	48,0005,2536	Ring rail 1422.4 mm (56 inch)
48,0005,2517	Ring rail 58.8 mm (22 inch)	48,0005,2537	Ring rail 1473.2 mm (58 inch)
48,0005,2518	Ring rail 609.6 mm (24 inch)	48,0005,2538	Ring rail 1524 mm (60 inch)
48,0005,2519	Ring rail 660.4 mm (26 inch)	48,0005,2539	Ring rail 1574.8 mm (62 inch)
48,0005,2520	Ring rail 711.2 mm (28 inch)	48,0005,2540	Ring rail 1625.6 mm (64 inch)
48,0005,2521	Ring rail 762 mm (30 inch)	48,0005,2541	Ring rail 1676.4 mm (66 inch)
48,0005,2522	Ring rail 812.8 mm (32 inch)	48,0005,2542	Ring rail 1727.2 mm (68 inch)
48,0005,2523	Ring rail 863.6 mm (34 inch)	48,0005,2543	Ring rail 1778 mm (70 inch)
48,0005,2524	Ring rail 914.4 mm (36 inch)		
48,0005,2525	Ring rail 965.2 mm (38 inch)	48,0005,2533	Magnetic bridge ring rail, height adjustment: 10 mm
48,0005,2526	Ring rail 1016 mm (40 inch)	48,0005,2534	Spring holder ring rail
48,0005,2527	Ring rail 1066.8 mm (42 inch)		
48,0005,2528	Ring rail 1117.6 mm (44 inch)		




Control box interior






Not shown in drawing: Micro-SD-Card, Art. No: 48,0005,0132




**FGU 8/SD80-28**



**Item no.: 8,045,641**





**FGU 9 / SD28**


**Item no.: 8,045,581**













**Mechanical seam tracking**

(no overall item number)




FTH 18/D16-25

Item no.: 48,0005,1752




FTH 21


Item no.: 48,0005,1777




### Closed ring rail




### Straight guide rails (rigid and flexible)






**Vacuum bridge  
with spacer block**


**Item no. 48,0005,1771**  
**Item no. 48,0005, 1886**




**Vacuum bridge  
with adjustment unit**


**Item no. 48,0005,1771**  
**Item no. 48,0005, 2083/48,0005,2085**








# Wiring diagram














# Declaration of conformity



## EU-KONFORMITÄTSERKLÄRUNG 2018 EU-DECLARATION OF CONFORMITY 2018 DÉCLARATION UE DE CONFORMITÉ, 2018

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

### FRONIUS INTERNATIONAL GMBH

Froniusstraße 1, A-4643 Pettenbach

erklärt in alleiniger Verantwortung,  
dass folgendes Produkt:

FlexTrack 45 PRO  
Fahrwerk

auf das sich diese Erklärung  
bezieht, mit folgenden Richtlinien  
bzw. Normen übereinstimmt:

Richtlinie 2014/35/EU  
Elektrische Betriebsmittel  
Niederspannungsrichtlinie

Richtlinie 2014/30/EU  
Elektromag. Verträglichkeit

Richtlinie 2011/65/EU  
RoHS

Richtlinie 2006/42/EG  
Maschinenrichtlinie

Europäische Normen inklusive  
zutreffende Änderungen  
EN ISO 12100:2010  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Hereby certifies on its sole  
responsibility that the following  
product:

FlexTrack 45 PRO  
Welding carriage

which is explicitly referred to by this  
Declaration meet the following  
directives and standard(s):

Directive 2014/35/EU  
Electrical Apparatus  
Low Voltage Directive

Directive 2014/30/EU  
Electromag. compatibility

Directive 2011/65/EU  
RoHS

Directive 2006/42/EC  
Machinery Directive

European Standards including  
relevant amendments  
EN ISO 12100:2010  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

se déclare seule responsable du fait  
que le produit suivant:

FlexTrack 45 PRO  
Chariot de soudage

qui est l'objet de la présente  
déclaration correspondent aux  
suivantes directives et normes:

Directive 2014/35/UE  
Outils électriques  
Directive de basse tension

Directive 2014/30/UE  
Électromag. Compatibilité

Directive 2011/65/UE  
RoHS

Directive 2006/42/CE  
Directive aux machines

Normes européennes avec  
amendements correspondants  
EN ISO 12100:2010  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Die oben genannte Firma hält  
Dokumentationen als Nachweis der  
Erfüllung der Sicherheitsziele und  
die wesentlichen Schutzanforderungen  
zur Einsicht bereit.

Dokumentationsverantwortlicher:  
(technische Dokumentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

Documentation evidencing  
conformity with the requirements of  
the Directives is kept available for  
inspection at the above  
Manufacturer.

person responsible for documents:  
(technical documents)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

En tant que preuve de la satisfaction  
des demandes de sécurité la  
documentation peut être consultée  
chez la compagnie susmentionnée.

responsible documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

CE 2018

ppa. T. Herndler, MAS

Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-KONFORMITÄTSERKLÄRUNG 2018  
EU-DECLARATION OF CONFORMITY 2018  
DÉCLARATION UE DE CONFORMITÉ, 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Froniusstraße 1, A-4643 Pettenbach

erklärt in alleiniger Verantwortung,  
dass folgendes Produkt:

e-cabinet  
Steuergerät

auf das sich diese Erklärung  
bezieht, mit folgenden Richtlinien  
bzw. Normen übereinstimmt:

Richtlinie 2014/35/EU  
Elektrische Betriebsmittel  
Niederspannungsrichtlinie

Richtlinie 2014/30/EU  
Elektromag. Verträglichkeit

Richtlinie 2011/65/EU  
RoHS

Europäische Normen inklusive  
zutreffende Änderungen  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Die oben genannte Firma hält  
Dokumentationen als Nachweis der  
Erfüllung der Sicherheitsziele und  
die wesentlichen Schutzanforder-  
ungen zur Einsicht bereit.

Hereby certifies on its sole  
responsibility that the following  
product:

e-cabinet  
Control unit

which is explicitly referred to by this  
Declaration meet the following  
directives and standard(s):

Directive 2014/35/EU  
Electrical Apparatus  
Low Voltage Directive

Directive 2014/30/EU  
Electromag. compatibility

Directive 2011/65/EU  
RoHS

European Standards including  
relevant amendments  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Documentation evidencing  
conformity with the requirements of  
the Directives is kept available for  
inspection at the above  
Manufacturer.

se déclare seule responsable du fait  
que le produit suivant:

e-cabinet  
Appareil de commande

qui est l'objet de la présente  
déclaration correspondent aux  
suivantes directives et normes:

Directive 2014/35/UE  
Outils électriques  
Directive de basse tension

Directive 2014/30/UE  
Électromag. Compatibilité

Directive 2011/65/UE  
RoHS

Normes européennes avec  
amendements correspondants  
EN 60204-1:2009  
EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

En tant que preuve de la satisfaction  
des demandes de sécurité la  
documentation peut être consultée  
chez la compagnie susmentionnée.

**CE**  
marking date: **2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German Deutsch

EN English English

FR French Française



**EU-KONFORMITÄTSERKLÄRUNG 2018  
EU-DECLARATION OF CONFORMITY 2018  
DÉCLARATION UE DE CONFORMITÉ, 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Froniusstraße 1, A-4643 Pettenbach

erklärt in alleiniger Verantwortung,  
dass folgendes Produkt:

FRC-45 Basic  
Fernbedienung

auf das sich diese Erklärung  
bezieht, mit folgenden Richtlinien  
bzw. Normen übereinstimmt:

Richtlinie 2014/30/EU  
Elektromag. Verträglichkeit

Richtlinie 2011/65/EU  
RoHS

Europäische Normen inklusive  
zutreffende Änderungen

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Die oben genannte Firma hält  
Dokumentationen als Nachweis der  
Erfüllung der Sicherheitsziele und  
die wesentlichen Schutzzanforder-  
ungen zur Einsicht bereit.

Hereby certifies on its sole  
responsibility that the following  
product:

FRC-45 Basic  
Remote control

which is explicitly referred to by this  
Declaration meet the following  
directives and standard(s):

Directive 2014/30/EU  
Electromag. compatibility

Directive 2011/65/EU  
RoHS

European Standards including  
relevant amendments

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Documentation evidencing  
conformity with the requirements of  
the Directives is kept available for  
inspection at the above  
Manufacturer.

se déclare seule responsable du fait  
que le produit suivant:

FRC-45 Basic  
Télécommande

qui est l'objet de la présente  
déclaration correspondent aux  
suivantes directives et normes:

Directive 2014/30/EU  
Électromag. Compatibilité

Directive 2011/65/EU  
RoHS

Normes européennes avec  
amendements correspondants

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

En tant que preuve de la satisfaction  
des demandes de sécurité la  
documentation peut être consultée  
chez la compagnie susmentionnée.

**CE** marking date: **2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-KONFORMITÄTSERKLÄRUNG 2018  
EU-DECLARATION OF CONFORMITY 2018  
DÉCLARATION UE DE CONFORMITÉ, 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Froniusstraße 1, A-4643 Pettenbach

erklärt in alleiniger Verantwortung,  
dass folgendes Produkt:

FRC-45 Pro  
Fernbedienung

auf das sich diese Erklärung  
bezieht, mit folgenden Richtlinien  
bzw. Normen übereinstimmt:

Richtlinie 2014/30/EU  
Elektromag. Verträglichkeit

Richtlinie 2011/65/EU  
RoHS

Europäische Normen inklusive  
zutreffende Änderungen

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Die oben genannte Firma hält  
Dokumentationen als Nachweis der  
Erfüllung der Sicherheitsziele und  
die wesentlichen Schutzanforder-  
ungen zur Einsicht bereit.

Hereby certifies on its sole  
responsibility that the following  
product:

FRC-45 Pro  
Remote control

which is explicitly referred to by this  
Declaration meet the following  
directives and standard(s):

Directive 2014/30/EU  
Electromag. compatibility

Directive 2011/65/EU  
RoHS

European Standards including  
relevant amendments

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

Documentation evidencing  
conformity with the requirements of  
the Directives is kept available for  
inspection at the above  
Manufacturer.

se déclare seule responsable du fait  
que le produit suivant:

FRC-45 Pro  
Télécommande

qui est l'objet de la présente  
déclaration correspondent aux  
suivantes directives et normes:

Directive 2014/30/UE  
Électromag. Compatibilité

Directive 2011/65/UE  
RoHS

Normes européennes avec  
amendements correspondants

EN 61000-6-2:2005+AC:2005  
EN 61000-6-4:2007+A1:2011

En tant que preuve de la satisfaction  
des demandes de sécurité la  
documentation peut être consultée  
chez la compagnie susmentionnée.

**CE** marking date: **2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-EINBAUERKLÄRUNG 2018  
EU DECLARATION OF INCORPORATION 2018  
DECLARATION D' INCORPORATION DE U.E., 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Fronius International GmbH  
Froniusstraße 1, A-4643 Pettenbach

Hiermit erklären wir, dass folgendes Produkt:

**FMS 50/ML15/SE/ACC**  
Schweißzubehör

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

**Anhang I: 1.1.3, 1.1.5, 1.3.1**

We hereby declare that the following product:

**FMS 50/ML15/SE/ACC**  
Arc welding equipment

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

**Annex I: 1.1.3, 1.1.5, 1.3.1**

Nous déclarons par la présente que le produit suivant:

**FMS 50/ML15/SE/ACC**  
Accessoires de soudage

répond aux exigences essentielles indiquées ci-dessous, relatives à celles d'une « quasi-machine » au sens de la directive machines 2006/42/CE. Le produit est exclusivement prévu pour un montage dans une machine ou une quasi-machine et ne répond donc pas encore à toutes les exigences de la directive machines. La mise en service du produit est interdite jusqu'à ce qu'il soit constaté que la machine dans laquelle le produit précité a été monté, est en conformité avec toutes les exigences de la directive machines 2006/42/CE. Les documents techniques spéciaux, conformément à l'annexe VII Partie B, ont été élaborés.

**Annexe I: 1.1.3, 1.1.5, 1.3.1**

Dokumentationsverantwortlicher:  
(technische Dokumentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

person responsible for documents:  
(technical documents)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

responsable documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-EINBAUERKLÄRUNG 2018  
EU DECLARATION OF INCORPORATION 2018  
DECLARATION D' INCORPORATION DE U.E., 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Fronius International GmbH  
Froniusstraße 1, A-4643 Pettenbach

Hiermit erklären wir, dass folgendes Produkt:

**FMS 100/ML15/SE/ACC**  
Schweißzubehör

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

We hereby declare that the following product:

**FMS 100/ML15/SE/ACC**  
Arc welding equipment

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it is has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

Nous déclarons par la présente que le produit suivant:

**FMS 100/ML15/SE/ACC**  
Accessoires de soudage

répond aux exigences essentielles indiquées ci-dessous, relatives à celles d'une « quasi-machine » au sens de la directive machines 2006/42/CE. Le produit est exclusivement prévu pour un montage dans une machine ou une quasi-machine et ne répond donc pas encore à toutes les exigences de la directive machines. La mise en service du produit est interdite jusqu'à ce qu'il soit constaté que la machine dans laquelle le produit précité a été monté, est en conformité avec toutes les exigences de la directive machines 2006/42/CE. Les documents techniques spéciaux, conformément à l'annexe VII Partie B, ont été élaborés.

**Anhang I: 1.1.3, 1.1.5, 1.3.1**

**Annex I: 1.1.3, 1.1.5, 1.3.1**

**Annexe I: 1.1.3, 1.1.5, 1.3.1**

Dokumentationsverantwortlicher:  
(technische Dokumentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

person responsible for documents:  
(technical documents)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

responsable documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-EINBAUERKLÄRUNG 2018  
EU DECLARATION OF INCORPORATION 2018  
DECLARATION D' INCORPORATION DE U.E., 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Fronius International GmbH  
Froniusstraße 1, A-4643 Pettenbach

Hiermit erklären wir, dass folgendes Produkt:

**FOU 30/ML6/radial**  
Schweißzubehör

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

We hereby declare that the following product:

**FOU 30/ML6/radial**  
Arc welding equipment

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it is has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

Nous déclarons par la présente que le produit suivant:

**FOU 30/ML6/radial**  
Accessoires de soudage

répond aux exigences essentielles indiquées ci-dessous, relatives à celles d'une « quasi-machine » au sens de la directive machines 2006/42/CE. Le produit est exclusivement prévu pour un montage dans une machine ou une quasi-machine et ne répond donc pas encore à toutes les exigences de la directive machines. La mise en service du produit est interdite jusqu'à ce qu'il soit constaté que la machine dans laquelle le produit précité a été monté, est en conformité avec toutes les exigences de la directive machines 2006/42/CE. Les documents techniques spéciaux, conformément à l'annexe VII Partie B, ont été élaborés.

**Anhang I: 1.1.3, 1.1.5, 1.3.1**

**Annex I: 1.1.3, 1.1.5, 1.3.1**

**Annexe I: 1.1.3, 1.1.5, 1.3.1**

Dokumentationsverantwortlicher:  
(technische Dokumentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

person responsible for documents:  
(technical documents)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

responsable documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**EU-EINBAUERKLÄRUNG 2018  
EU DECLARATION OF INCORPORATION 2018  
DECLARATION D' INCORPORATION DE U.E., 2018**

Wels-Thalheim, 2018-01-16

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**

Fronius International GmbH  
Froniusstraße 1, A-4643 Pettenbach

Hiermit erklären wir, dass folgendes Produkt:

FOU 30/ML10/linear  
Schweißzubehör

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

Anhang I: 1.1.3, 1.1.5, 1.3.1

We hereby declare that the following product:

FOU 30/ML10/linear  
Arc welding equipment

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it is has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

Annex I: 1.1.3, 1.1.5, 1.3.1

Nous déclarons par la présente que le produit suivant:

FOU 30/ML10/linear  
Accessoires de soudage

répond aux exigences essentielles indiquées ci-dessous, relatives à celles d'une « quasi-machine » au sens de la directive machines 2006/42/CE. Le produit est exclusivement prévu pour un montage dans une machine ou une quasi-machine et ne répond donc pas encore à toutes les exigences de la directive machines. La mise en service du produit est interdite jusqu'à ce qu'il soit constaté que la machine dans laquelle le produit précité a été monté, est en conformité avec toutes les exigences de la directive machines 2006/42/CE. Les documents techniques spéciaux, conformément à l'annexe VII Partie B, ont été élaborés.

Annexe I: 1.1.3, 1.1.5, 1.3.1

Dokumentationsverantwortlicher:  
(technische Dokumentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

person responsible for documents:  
(technical documents)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

responsable documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2018**

ppa. T. Herndl, MAS  
Member of Board  
Chief Production Officer

DE German

Deutsch

EN English

English

FR French

Française



**FRONIUS INTERNATIONAL GMBH**

**TechSupport Automation**

Froniusplatz 1, A-4600 Wels, Austria

E-Mail: support.automation@fronius.com  
**[www.fronius.com](http://www.fronius.com)**

**[www.fronius.com/addresses](http://www.fronius.com/addresses)**

Under <http://www.fronius.com/addresses> you will find all addresses  
of our Sales & service partners and Locations.

